

**DTC U0415:68**

id030200201400

<b>DTC U0415:68</b>	<b>Abnormal message from DSC HU/CM</b>
<b>DETECTION CONDITION</b>	• Correct data cannot be received from DSC HU/CM
<b>FAIL-SAFE FUNCTION</b>	• Control disabled.
<b>POSSIBLE CAUSE</b>	• DSC HU/CM malfunction

**Diagnostic procedure**

<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>
1	<b>INSPECT FOR DSC HU/CM MALFUNCTION</b> <ul style="list-style-type: none"><li>• Switch the ignition to off.</li><li>• Using the M-MDS, perform the DTC inspection for the DSC HU/CM. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)</li><li>• Are any DTCs detected?</li></ul>	Yes Go to applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)
		No Go to the next step.
2	<b>VERIFY THAT THE SAME DTC IS NOT PRESENT</b> <ul style="list-style-type: none"><li>• Clear the DTCs from the memory. (See ELECTRONIC 4WD CONTROL SYSTEM ON-BOARD DIAGNOSIS.)</li><li>• Are the same DTCs present?</li></ul>	Yes Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION.)
		No Go to the next step.
3	<b>VERIFY THAT NO OTHER DTCS ARE PRESENT</b> <ul style="list-style-type: none"><li>• Are any other DTCs output?</li></ul>	Yes Go to the applicable DTC inspection. (See ELECTRONIC 4WD CONTROL SYSTEM ON-BOARD DIAGNOSIS.)
		No DTC troubleshooting completed.