


# DTC P0A94:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4004400

## Details On DTCs

DESCRIPTION	DC-DC converter: control circuit signal error	
DETECTION CONDITION	Determination conditions	<ul style="list-style-type: none"> <li>Internal malfunction signal from DC-DC converter via front body control module (FBCM) is received.(CAN/LIN communication).</li> <li>Input signal from the DC-DC converter limits the pressure increase time.</li> <li>Input signal from the DC-DC converter does not implement pressure increase after a pressure increase command to the DC-DC converter.</li> </ul>
	Preconditions	<ul style="list-style-type: none"> <li>Not applicable</li> </ul>
	Drive cycle	<ul style="list-style-type: none"> <li>1</li> </ul>
	Self test type	<ul style="list-style-type: none"> <li>CMDTC self test</li> </ul>
	Sensor used	<ul style="list-style-type: none"> <li>Not applicable</li> </ul>
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> <li>Inhibits engine-stop by operating the i-stop function.</li> </ul>	
VEHICLE STATUS WHEN DTCs ARE OUTPUT	<ul style="list-style-type: none"> <li>Flashes i-stop warning light (amber).</li> </ul>	
POSSIBLE CAUSE	<ul style="list-style-type: none"> <li>Connector or terminal malfunction of the following parts: <ul style="list-style-type: none"> <li>PCM</li> <li>Battery</li> <li>DC-DC converter</li> </ul> </li> <li>Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>DC-DC converter terminal L—DCDC 50 A fuse</li> <li>DCDC 50 A fuse</li> <li>Battery positive terminal—DCDC 50 A fuse</li> </ul> </li> <li>Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>DC-DC converter terminal L—DCDC 50 A fuse</li> <li>DCDC 50 A fuse</li> <li>Battery positive terminal—DCDC 50 A fuse</li> </ul> </li> <li>Battery malfunction</li> <li>DC-DC converter malfunction</li> <li>Front body control module (FBCM) malfunction</li> <li>PCM malfunction</li> </ul>	

## System Wiring Diagram



ac5wzw00006523

### Function Explanation (DTC Detection Outline)

- The DC-DC converter is equipped with a boost function to stabilize the power supply to the vehicle's electrical devices when the engine is restarted by i-stop. If the DC-DC converter does not operate, the supply voltage to the vehicle's electrical devices decreases. In this diagnostic, the response condition of the DC-DC converter to the boost demand from the PCM, or the boost by the on-board diagnostic function of the DC-DC converter is not detected, and verification of vehicle malfunctions/safety assurance is performed.

### Repeatability Verification Procedure

1. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
2. Start the engine.
3. Stop the engine by operating the i-stop function.

### PID Item/Simulation Item Used In Diagnosis

- Not applicable

### Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	<b>PURPOSE: VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"><li>• Verify related Service Information availability.</li><li>• Is any related Service Information available?</li></ul>	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"><li>• If the vehicle is not repaired, go to the next step.</li></ul>
		No	Go to the next step.
2	<b>PURPOSE: VERIFY IF BATTERY VOLTAGE IS FALSELY RECOGNIZED BY DTC RELATED CAN OR LIN COMMUNICATION</b> <ul style="list-style-type: none"><li>• Perform the PCM and front body control module (FBCM) DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)</li><li>• Are DTCs related CAN or LIN communication recorded?</li></ul>	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the troubleshooting procedure to perform the procedure from Step 1.
3	<b>PURPOSE: VERIFY IF THE CURRENT SENSOR IS MISIDENTIFYING MALFUNCTIONS DUE TO A FBCM MALFUNCTION</b> <ul style="list-style-type: none"><li>• Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)</li><li>• Is the PENDING CODE for this DTC present?</li></ul>	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the troubleshooting procedure to perform the procedure from Step 1.

### Troubleshooting Diagnostic Procedure

#### Intention of troubleshooting procedure

- Step 1
  - Perform a unit inspection of the battery.
- Step 2—8
  - Verify if a malfunction is occurring due to a malfunction in each signal transmission and the boost demand line.
- Step 9—10
  - Verify that the primary malfunction is resolved and there are no other malfunctions.

### Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<b>INSPECT BATTERY</b> <ul style="list-style-type: none"><li>• Switch the ignition off.</li><li>• Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li><li>• Is there any malfunction?</li></ul>	Yes	Recharge or replace the battery, then go to Step 8. (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
2	<b>INSPECT DC-DC CONVERTER CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the DC-DC converter connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
3	<b>INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter connector is disconnected.</li> <li>• Measure the voltage at the DC-DC converter terminal L (wiring harness-side).</li> <li>• Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the DCDC 50 A fuse. <ul style="list-style-type: none"> <li>• If the fuse is blown:               <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness for a possible short to ground.</li> <li>— Replace the fuse.</li> </ul> </li> <li>• If the fuse is deteriorated:               <ul style="list-style-type: none"> <li>— Replace the fuse.</li> </ul> </li> <li>• If the fuse is normal:               <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness for a possible open circuit.</li> </ul> </li> </ul> Go to Step 8.
4	<b>INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter connector is disconnected.</li> <li>• Inspect for continuity between DC-DC converter terminal F (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness for a possible short to ground.</li> </ul> If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> Go to Step 8.
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	<b>INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter and PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> <li>• Measure the voltage at the DC-DC converter terminal F (wiring harness-side).</li> <li>• Is the voltage <b>0 V</b>?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
7	<b>INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the DC-DC converter and PCM connectors are disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between DC-DC converter terminal F (wiring harness-side) and PCM terminal 2P (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 8.
8	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Replace the DC-DC converter, and then perform Step 8 again. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> Go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
9	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.