

NO SOUND FROM ALL SPEAKERS [ENTIRE AUDIO SYSTEM]

id0903e2100700

Without Bose®

Possible DTC	No sound from all speakers	
	Using the M-MDS	U3003:16, U3000:09
	Without using M-MDS (On-board diagnostic test mode)	09:Er20, 09:Er21
Possible cause	<ul style="list-style-type: none"> • Electronic jamming from outside, or inferior condition of broadcasting station radio wave • Glass antenna malfunction • Antenna feeder malfunction • Center roof antenna malfunction • Speaker muted by Bluetooth system (hands-free telephone (HF/TEL) system) operation • Poor connection of music device • Volume adjustment of music device is at minimum • Poor connection at audio unit connector, terminal damage • Audio unit malfunction • Short circuit in wiring harness between audio unit and speaker • Open circuit in wiring harness between audio unit and speaker • Short circuit inside speaker • Speaker malfunction 	

Diagnostic procedure

STEP	INSPECTION	ACTION	
1	• It sound not output from the speaker only while in radio mode?	Yes	Go to the next step.
		No	Go to Step 6.
2	• Does noise occur?	Yes	Go to the next step.
		No	Go to Step 8.
3	• Can the location where the noise occurs be specified?	Yes	The system is normal. Explain to the customer that the noise is caused by radio wave disturbances or broadcast wave conditions from the outside.
		No	Go to the next step.
4	• Compare the radio broadcast reception condition on another vehicle of the same model (model/unit) in the location where the noise occurs. • Compared to another vehicle of the same model, is the reception worse?	Yes	Go to the next step.
		No	Go to Step 6.
5	• Inspect the glass antenna and antenna feeder. • Are the glass antenna and antenna feeder normal?	Yes	Go to the next step.
		No	Repair or replace the glass antenna and/or the antenna feeder.
6	• Does the Bluetooth system (hands-free telephone (HF/TEL) system) operate?	Yes	The system is normal. Explain to the customer that the Bluetooth system (hands-free telephone (HF/TEL) system) operates and the speaker is muted.
		No	Go to the next step.
7	• Does the AUX mode operate?	Yes	Verify the volume of the music device which has been connected. If sound is output, go to the next step.
		No	Go to the next step.
8	• Connect the audio unit connector. • Inspect the voltage for the power supply line (B +, ACC). Specification: Switch the ignition to ON: 11.5 V or more Idle: 12.5 V or more • Is the voltage normal?	Yes	Go to the next step.
		No	Charge the battery, then go to the next step.
9	• Play the CD or Radio. • Adjust the volume between "10" to "15". • Is there sound?	Yes	The system is normal.
		No	Go to the next step.

STEP	INSPECTION	ACTION
10	<ul style="list-style-type: none"> Switch the ignition to off. Remove the audio unit. Disconnect the audio unit connector (24-pin). Inspect the continuity between the audio unit wiring harness-side connector terminal and ground: <p>For front door speaker</p> <ul style="list-style-type: none"> Terminal 1A (LH+)—GND Terminal 1C (LH-)—GND Terminal 1D (RH+)—GND Terminal 1F (RH-)—GND <p>For rear door speaker</p> <ul style="list-style-type: none"> Terminal 1S (LH+)—GND Terminal 1U (LH-)—GND Terminal 1V (RH+)—GND Terminal 1X (RH-)—GND <ul style="list-style-type: none"> Disconnect the front door speaker connector (4-pin) Inspect the continuity between the front door speaker wiring harness-side connector terminal and ground: <p>For tweeter</p> <ul style="list-style-type: none"> Terminal 1A (LH+)—GND Terminal 1C (LH-)—GND Terminal 1D (RH+)—GND Terminal 1F (RH-)—GND <ul style="list-style-type: none"> Is there continuity? 	<p>Yes</p> <p>Repair or replace the suspect wiring harness or speaker unit.</p> <p>Note</p> <ul style="list-style-type: none"> If there is a short circuit between the speaker harness or speaker lead wire and ground, the protector circuit inside the audio unit operates to cut the sound. <p>No</p> <ul style="list-style-type: none"> Replace the audio unit. (See AUDIO UNIT REMOVAL/INSTALLATION.)

With Bose®

Possible DTC	No sound from all speakers	
	Using the M-MDS	U3003:16, U3000:09
	Without using M-MDS (On-board diagnostic test mode)	09:Er20, 09:Er21
Possible cause	<ul style="list-style-type: none"> Electronic jamming from outside, or inferior condition of broadcasting station radio wave Glass antenna malfunction Antenna feeder malfunction Center roof antenna malfunction Speaker muted by Bluetooth system (hands-free telephone (HF/TEL) system) operation Poor connection of music device Volume adjustment of music device is at minimum Speaker malfunction Audio amplifier malfunction Audio unit malfunction Open or short circuit in wiring harness between audio amplifier and audio unit Poor connection of audio unit or audio amplifier connector, terminal damage CAN signal wiring harness malfunction Short circuit inside speaker Open or short circuit in wiring harness between audio amplifier and speaker 	

Diagnostic procedure

STEP	INSPECTION	ACTION
1	• It sound not output from the speaker only while in radio mode?	<p>Yes</p> <p>Go to the next step.</p> <p>No</p> <p>Go to Step 6.</p>
2	• Does noise occur?	<p>Yes</p> <p>Go to the next step.</p> <p>No</p> <p>Go to Step 8.</p>
3	• Can the location where the noise occurs be specified?	<p>Yes</p> <p>The system is normal. Explain to the customer that the noise is caused by radio wave disturbances or broadcast wave conditions from the outside.</p> <p>No</p> <p>Go to the next step.</p>

STEP	INSPECTION		ACTION
4	<ul style="list-style-type: none"> Compare the radio broadcast reception condition on another vehicle of the same model (model/unit) in the location where the noise occurs. Compared to another vehicle of the same model, is the reception worse? 	Yes	Go to the next step.
		No	Go to Step 6.
5	<ul style="list-style-type: none"> Inspect the glass antenna and antenna feeder. Are the glass antenna and antenna feeder normal? 	Yes	Go to the next step.
		No	Repair or replace the glass antenna and/or the antenna feeder.
6	<ul style="list-style-type: none"> Does the Bluetooth system (hands-free telephone (HF/TEL) system) operate? 	Yes	The system is normal. Explain to the customer that the Bluetooth system (hands-free telephone (HF/TEL) system) operates and the speaker is muted.
		No	Go to the next step.
7	<ul style="list-style-type: none"> Does the AUX mode operate? 	Yes	Verify the volume of the music device which has been connected. If sound is output, go to the next step.
		No	Go to the next step.
8	<ul style="list-style-type: none"> Connect the audio unit connector. Inspect the voltage for the power supply line (B+, ACC). Specification: Switch the ignition to ON: 11.5 V or more Idle: 12.5 V or more Is the voltage normal? 	Yes	Go to the next step.
		No	Charge the battery, then go to the next step.
9	<ul style="list-style-type: none"> Play CD or radio. Adjust the volume between "10" and "15". Is there sound? 	Yes	The system is normal.
		No	Go to the next step.
10	<ul style="list-style-type: none"> Measure the voltage at the audio amplifier terminal 3A. (8-pin, vehicle harness-side) Is the voltage B+? 	Yes	Go to the next step.
		No	Repair or replace wiring harness between the audio amplifier and fuse. Go to the next step.
11	<ul style="list-style-type: none"> Inspect the connection of audio unit connector (24-pin) and audio amplifier connectors for poor connection (such as damaged/pulled-out pins, corrosion). Are all pins normal? 	Yes	Go to the next step.
		No	Repair or replace the pins and/or the connector.

STEP	INSPECTION	ACTION	
12	<ul style="list-style-type: none"> Switch the ignition to off. Disconnect the audio amplifier connector. Inspect continuity between the following terminals of the audio amplifier connector and speaker connector. For front door speaker (LH) <ul style="list-style-type: none"> Terminal 3F (L.H.D.)/3C (R.H.D.)—Terminal C Terminal 3E (L.H.D.)/3D (R.H.D.)—Terminal B For front door speaker (RH) <ul style="list-style-type: none"> Terminal 3C (L.H.D.)/3F (R.H.D.)—Terminal C Terminal 3D (L.H.D.)/3E (R.H.D.)—Terminal B For tweeter (LH) <ul style="list-style-type: none"> Terminal 2G (L.H.D.)/2C (R.H.D.)—Terminal B Terminal 2I (L.H.D.)/2E (R.H.D.)—Terminal A For tweeter (RH) <ul style="list-style-type: none"> Terminal 2C (L.H.D.)/2G (R.H.D.)—Terminal B Terminal 2E (L.H.D.)/2I (R.H.D.)—Terminal A For rear door speaker (LH) <ul style="list-style-type: none"> Terminal 2O (L.H.D.)/2M (R.H.D.)—Terminal C Terminal 2P (L.H.D.)/2K (R.H.D.)—Terminal B For rear door speaker (RH) <ul style="list-style-type: none"> Terminal 2M (L.H.D.)/2O (R.H.D.)—Terminal C Terminal 2K (L.H.D.)/2P (R.H.D.)—Terminal B For front center speaker <ul style="list-style-type: none"> Terminal 3G—Terminal B Terminal 3H—Terminal A For D-pillar speaker <ul style="list-style-type: none"> Terminal 2A—Terminal B Terminal 2B—Terminal A <ul style="list-style-type: none"> Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the repair related wiring harnesses.

STEP	INSPECTION	ACTION	
13	<ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the audio amplifier connector. • Inspect the continuity between the audio amplifier connector and ground: For front door speaker (LH) <ul style="list-style-type: none"> — Terminal 3F (L.H.D.)/3C (R.H.D.)—GND — Terminal 3E (L.H.D.)/3D (R.H.D.)—GND For front door speaker (RH) <ul style="list-style-type: none"> — Terminal 3C (L.H.D.)/3F (R.H.D.)—GND — Terminal 3D (L.H.D.)/3E (R.H.D.)—GND For tweeter (LH) <ul style="list-style-type: none"> — Terminal 2G (L.H.D.)/2C (R.H.D.)—GND — Terminal 2I (L.H.D.)/2E (R.H.D.)—GND For tweeter (RH) <ul style="list-style-type: none"> — Terminal 2C (L.H.D.)/2G (R.H.D.)—GND — Terminal 2E (L.H.D.)/2I (R.H.D.)—GND For rear door speaker (LH) <ul style="list-style-type: none"> — Terminal 2O (L.H.D.)/2M (R.H.D.)—GND — Terminal 2P (L.H.D.)/2K (R.H.D.)—GND For rear door speaker (RH) <ul style="list-style-type: none"> — Terminal 2M (L.H.D.)/2O (R.H.D.)—GND — Terminal 2K (L.H.D.)/2P (R.H.D.)—GND For front center speaker <ul style="list-style-type: none"> — Terminal 3G—GND — Terminal 3H—GND For D-pillar speaker <ul style="list-style-type: none"> — Terminal 2A—GND — Terminal 2B—GND <ul style="list-style-type: none"> • Is there continuity? 	Yes	Repair or replace the related wiring harness or speaker. (See FRONT DOOR SPEAKER REMOVAL/INSTALLATION.) (See TWEETER REMOVAL/INSTALLATION.) (See REAR DOOR SPEAKER REMOVAL/INSTALLATION.) (See FRONT CENTER SPEAKER REMOVAL/INSTALLATION.) (See D-PILLAR SPEAKER REMOVAL/INSTALLATION.)
		No	Go to the next step. <div> Note <ul style="list-style-type: none"> • If there is a short circuit between the speaker harness or speaker lead wire and ground, the protector circuit inside the audio unit operates to cut the sound. </div>
14	<ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the audio amplifier connector and audio unit connector (24-pin). • Inspect the continuity between the audio amplifier terminal 2F (16-pin, vehicle harness-side) and audio unit terminal 1J (24-pin, vehicle harness-side). • Is there continuity? 	Yes	Replace the audio amplifier. (See AUDIO AMPLIFIER REMOVAL/INSTALLATION.)
		No	Repair or replace the wiring harness between the audio amplifier and audio unit. Then go to the next step.
15	<ul style="list-style-type: none"> • Is there any sound? 	Yes	The system is normal.
		No	Replace the audio amplifier. (See AUDIO AMPLIFIER REMOVAL/INSTALLATION.)