

**DTC U1A4B:43, U1A4B:44, U1A4B:45, U1A4B:46, U1A4B:47, U1A4B:48, U1A4B:49, U1A4B:96 [REAR VEHICLE MONITORING SYSTEM]**

id0902z2887800

System malfunction location	Rear vehicle monitoring control module (LH) malfunction
Detection condition	<ul style="list-style-type: none"> <li>• U1A4B:43 — Rear vehicle monitoring control module (LH) external RAM malfunction detected.</li> <li>• U1A4B:44 — Rear vehicle monitoring control module (LH) internal RAM malfunction detected.</li> <li>• U1A4B:45 — Rear vehicle monitoring control module (LH) ROM malfunction detected.</li> <li>• U1A4B:46 — Rear vehicle monitoring control module (LH) EEPROM malfunction detected.</li> <li>• U1A4B:47 — Rear vehicle monitoring control module (LH) monitoring system malfunction detected.</li> <li>• U1A4B:48 — Rear vehicle monitoring control module (LH) communication circuit malfunction detected.</li> <li>• U1A4B:49 — Rear vehicle monitoring control module (LH) voltage control circuit malfunction detected.</li> <li>• U1A4B:96 — Rear vehicle monitoring control module (LH) internal circuit malfunction detected.</li> </ul>
Fail-safe	<ul style="list-style-type: none"> <li>• U1A4B:43 — Inhibits the rear vehicle monitoring system.</li> <li>• U1A4B:44 — Inhibits the rear vehicle monitoring system.</li> <li>• U1A4B:45 — Inhibits the rear vehicle monitoring system.</li> <li>• U1A4B:46 — Inhibits the rear vehicle monitoring system.</li> <li>• U1A4B:47 — Inhibits the rear vehicle monitoring system.</li> <li>• U1A4B:48 — Inhibits the rear vehicle monitoring system.</li> <li>• U1A4B:49 — Inhibits the rear vehicle monitoring system.</li> <li>• U1A4B:96 — Inhibits the rear vehicle monitoring system.</li> </ul>
Possible cause	• Rear vehicle monitoring control module (LH) malfunction
System wiring diagram	—

**Diagnostic Procedure**

Step	Inspection	Action
1	<b>PERFORM DTC INSPECTION AND VERIFY REAR VEHICLE MONITORING CONTROL MODULE (LH) MALFUNCTION</b> <ul style="list-style-type: none"> <li>• Clear the DTC for the rear vehicle monitoring control module using the M-MDS. (See CLEARING DTC [REAR VEHICLE MONITORING SYSTEM].)</li> <li>• Switch the ignition ON (engine off or on) and wait for <b>1.5 s or more</b>.</li> <li>• Perform the DTC inspection for the rear vehicle monitoring control module using the M-MDS. (See DTC INSPECTION [REAR VEHICLE MONITORING SYSTEM].)</li> <li>• Are DTCs U1A4B:43/U1A4B:44/U1A4B:45/U1A4B:46/U1A4B:47/U1A4B:48/U1A4B:49/U1A4B:96 displayed?</li> </ul>	Yes Replace the rear vehicle monitoring control module (LH), then go to the next step. (See REAR VEHICLE MONITORING CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.

---

Step	Inspection		Action
2	<b>VERIFY IF OTHER DTCs DISPLAYED</b> • Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR VEHICLE MONITORING SYSTEM].)
		No	DTC troubleshooting completed.