


DTC C0031:11/C0031:15/C0034:11/C0034:15/C0037:11/C0037:15/C003A:11/C003A:15 [DYNAMIC STABILITY CONTROL (DSC)]

id0402b2180700

DTC	C0031:11, C0031:15	LF ABS wheel-speed sensor
	C0034:11, C0034:15	RF ABS wheel-speed sensor
	C0037:11, C0037:15	LR ABS wheel-speed sensor
	C003A:11, C003A:15	RR ABS wheel-speed sensor
DETECTION CONDITION	<ul style="list-style-type: none"> • C0031:11, C0034:11, C0037:11, C003A:11 <ul style="list-style-type: none"> — Short to ground has been detected in the ABS wheel-speed sensor wiring harness on any of the four vehicle wheels. • C0031:15, C0034:15, C0037:15, C003A:15 <ul style="list-style-type: none"> — Open circuit or short to power supply has been detected in the ABS wheel-speed sensor wiring harness on any of the four vehicle wheels. 	
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • Illuminates the ABS warning light, TCS/DSC indicator light, and master warning light^{*1}. • Tire pressure monitoring system warning light illuminates after flashes. • Inhibits the ABS, TCS, DSC, roll over mitigation (ROM), brake assist control, vehicle roll prevention function^{*2}, hill launch assist (HLA), TPMS, smart city brake support (SCBS)^{*1}, and secondary collision reduction (SCR) controls. (Additionally, when any malfunction is detected in two wheels or more, EBD control is inhibited and the brake system warning light is illuminated.) <p>^{*1}: Vehicles with smart city brake support (SCBS)</p> <p>^{*2}: ATX only</p>	
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Open circuit or short to ground/power supply in the wiring harness between the following DSC HU/CM terminals and ABS wheel-speed sensor terminals: <ul style="list-style-type: none"> — DSC HU/CM terminal F—RF ABS wheel-speed sensor terminal A — DSC HU/CM terminal C—RF ABS wheel-speed sensor terminal B — DSC HU/CM terminal AG—LF ABS wheel-speed sensor terminal A — DSC HU/CM terminal AJ—LF ABS wheel-speed sensor terminal B — DSC HU/CM terminal AA—RR ABS wheel-speed sensor terminal A — DSC HU/CM terminal X—RR ABS wheel-speed sensor terminal B — DSC HU/CM terminal L—LR ABS wheel-speed sensor terminal A — DSC HU/CM terminal O—LR ABS wheel-speed sensor terminal B • Malfunction in the ABS wheel-speed sensor • Poor connection at connectors (female terminal) 	



Diagnostic procedure

STEP	INSPECTION	ACTION
1	INSPECT ABS WHEEL-SPEED SENSOR FOR SHORT TO GROUND <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the DSC HU/CM connectors. Inspect for continuity between the following DSC HU/CM connector terminals (vehicle harness-side) and body ground: <ul style="list-style-type: none"> RF ABS wheel-speed sensor (+): F RF ABS wheel-speed sensor (-): C LF ABS wheel-speed sensor (+): AG LF ABS wheel-speed sensor (-): AJ RR ABS wheel-speed sensor (+): AA RR ABS wheel-speed sensor (-): X LR ABS wheel-speed sensor (+): L LR ABS wheel-speed sensor (-): O Is there continuity? 	<div>Yes</div> Go to the next step. <div>No</div> Go to Step 3.

STEP	INSPECTION	ACTION	
2	INSPECT ABS WHEEL-SPEED SENSOR WIRING HARNESS FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the ABS wheel-speed sensor connectors. • Inspect for continuity between the following DSC HU/CM connector terminals (vehicle harness-side) and body ground: <ul style="list-style-type: none"> — RF ABS wheel-speed sensor (+): F — RF ABS wheel-speed sensor (-): C — LF ABS wheel-speed sensor (+): AG — LF ABS wheel-speed sensor (-): AJ — RR ABS wheel-speed sensor (+): AA — RR ABS wheel-speed sensor (-): X — LR ABS wheel-speed sensor (+): L — LR ABS wheel-speed sensor (-): O • Is there continuity? 	Yes	Repair or replace the wiring harness, then go to Step 5.
		No	Replace the ABS wheel-speed sensor, then go to Step 5. (See FRONT ABS WHEEL-SPEED SENSOR REMOVAL/INSTALLATION.) (See REAR ABS WHEEL-SPEED SENSOR REMOVAL/INSTALLATION.)
3	INSPECT FOR OPEN CIRCUIT IN ABS WHEEL-SPEED SENSOR WIRING HARNESS <ul style="list-style-type: none"> • Inspect for continuity between the DSC HU/CM connectors (vehicle harness-side) and the following vehicle harness-side connector terminals of the ABS wheel-speed sensors: <ul style="list-style-type: none"> — RF ABS wheel-speed sensor (+): F—A — RF ABS wheel-speed sensor (-): C—B — LF ABS wheel-speed sensor (+): AG—A — LF ABS wheel-speed sensor (-): AJ—B — RR ABS wheel-speed sensor (+): AA—A — RR ABS wheel-speed sensor (-): X—B — LR ABS wheel-speed sensor (+): L—A — LR ABS wheel-speed sensor (-): O—B • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness, then go to the next step.
4	INSPECT ABS WHEEL-SPEED SENSOR WIRING HARNESS FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Inspect for voltage between the following DSC HU/CM connector terminals (vehicle harness-side) and body ground: <ul style="list-style-type: none"> — RF ABS wheel-speed sensor (+): F — RF ABS wheel-speed sensor (-): C — LF ABS wheel-speed sensor (+): AG — LF ABS wheel-speed sensor (-): AJ — RR ABS wheel-speed sensor (+): AA — RR ABS wheel-speed sensor (-): X — LR ABS wheel-speed sensor (+): L — LR ABS wheel-speed sensor (-): O • Is the voltage 1 V or less? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness, then go to the next step.
5	VERIFY THAT THE SAME DTC IS NOT PRESENT <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Clear the DTCs from the memory. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) • Are the same DTCs present? 	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION.)
		No	Go to the next step.
6	VERIFY THAT NO OTHER DTCS ARE PRESENT <ul style="list-style-type: none"> • Are any other DTCs output? 	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)
		No	DTC troubleshooting completed.