

DTC P0031:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4700400

DTC P0031:00	A/F sensor heater control circuit low input
DETECTION CONDITION	<ul style="list-style-type: none">• The PCM monitors the A/F sensor heater output voltage. If the PCM turns the A/F sensor heater off but the A/F sensor heater circuit remains low voltage, the PCM determines that the A/F sensor heater circuit has a malfunction. Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (A/F sensor heater, HO2S heater).• The check engine light illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM.• PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Stops fuel feedback control
POSSIBLE CAUSE	<ul style="list-style-type: none">• A/F sensor connector or terminals malfunction• Short to ground or open circuit in A/F sensor heater power supply circuit:<ul style="list-style-type: none">— Short to ground in wiring harness between ENGINE1 15 A fuse and A/F sensor terminal A— ENGINE1 15 A fuse malfunction— Open circuit in wiring harness between main relay terminal C and A/F sensor terminal A• PCM connector or terminals malfunction• Short to ground in wiring harness between A/F sensor terminal E and PCM terminal 1BY• A/F sensor heater malfunction• Open circuit in wiring harness between A/F sensor terminal E and PCM terminal 1BY• PCM malfunction

MAIN RELAY
TERMINAL C

④

④

ENGINE1 15 A

③

⑦

A/F SENSOR HEATER
(A/F SENSOR)

A

E

③

⑥

⑧

⑤

1BY

PCM

A/F SENSOR
WIRING HARNESS-SIDE
CONNECTOR

E

C

A

F

D

B

PCM WIRING HARNESS-SIDE CONNECTOR

1EE

1EA

1DW

1DS

1DO

1DK

1DG

1EF

1EB

1DX

1DT

1DP

1DL

1DH

1DA

1CW

1CS

1CO

1CK

1CG

1CC

1BY

1DB

1CX

1CT

1CP

1CL

1CH

1CD

1BZ

1BR

1BM

1BH

1BC

1AX

1AS

1AN

1AI

1BS

1BN

1BI

1BD

1AY

1AT

1AO

1AJ

1BT

1BO

1BJ

1BE

1AZ

1AU

1AP

1AK

1BU

1BP

1BK

1BF

1BA

1AV

1AQ

1AL

1BV

1BQ

1BL

1BG

1BB

1AW

1AR

1AM

1AD

1Y

1T

1O

1J

1E

1A

1AE

1Z

1U

1P

1K

1F

1B

1AF

1AA

1V

1Q

1L

1G

1C

1AG

1AB

1W

1R

1M

1H

1D

1AH

1AC

1X

1S

1N

1I

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS HAVE BEEN RECORDED <ul style="list-style-type: none"> Have the FREEZE FRAME DATA (Mode 2)/ snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor heater, HO2S heater related) been recorded? 	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	INSPECT A/F SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the A/F sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes Repair or replace the connector and/or terminals, then go to Step 9.
		No Go to the next step.
4	INSPECT A/F SENSOR HEATER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the A/F sensor connector is disconnected. Switch the ignition ON (engine off). Measure the voltage at the A/F sensor terminal A (wiring harness-side). Is the voltage B+? 	Yes Go to the next step.
		No Inspect the ENGINE1 15 A fuse. • If the fuse is blown: — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: — Replace the fuse. • If the fuse is normal: — Repair or replace the wiring harness for a possible open circuit. Go to Step 9.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes Repair or replace the connector and/or terminals, then go to Step 9.
		No Go to the next step.
6	INSPECT A/F SENSOR HEATER CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the A/F sensor and PCM connectors are disconnected. Inspect for continuity between A/F sensor terminal E (wiring harness-side) and body ground. Is there continuity? 	Yes Repair or replace the wiring harness for a possible short to ground, then go to Step 9.
		No Go to the next step.
7	INSPECT A/F SENSOR HEATER <ul style="list-style-type: none"> Inspect the A/F sensor heater. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/ INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes Replace the A/F sensor, then go to Step 9. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/ INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No Go to the next step.
8	INSPECT A/F SENSOR HEATER CONTROL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the A/F sensor and PCM connectors are disconnected. Inspect for continuity between A/F sensor terminal E (wiring harness-side) and PCM terminal 1BY (wiring harness-side). Is there continuity? 	Yes Go to the next step.
		No Repair or replace the wiring harness for a possible open circuit, then go to the next step.

STEP	INSPECTION	ACTION	
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is the PENDING CODE for this DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.