

## DTC U3000:41 [INSTRUMENT CLUSTER]

id0902e8999500

<b>System malfunction location</b>	Malfunction inside instrument cluster
<b>Detection condition</b>	• Malfunction inside instrument cluster detected.
<b>Fail-safe</b>	—
<b>Possible cause</b>	• Instrument cluster malfunction
<b>System wiring diagram</b>	—

### Diagnostic Procedure

Diagnostic Procedure			
Step	Inspection		Action
1	<b>PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS INSTRUMENT CLUSTER</b> <ul style="list-style-type: none"><li>• Clear DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].)</li><li>• Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].)</li><li>• Is DTC U3000:41 displayed?</li></ul>	Yes	Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Go to the next step.
2	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"><li>• Are any other DTCs displayed?</li></ul>	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	DTC troubleshooting completed.