

Caution


- Vehicle specifications differ depending on the vehicle identification number (VIN).
 - Type A VIN:
 - JM0 KE***** 100001—
 - JM6 KE***** 100001—
 - JM8 KE***** 100001—
 - JMZ KE***** 100001—
 - Type B VIN:
 - JM0 KE***** 200001—
 - JM6 KE***** 200001—
 - JM8 KE***** 200001—
 - JMZ KE***** 200001—

DTC P0670:00	Glow control module control circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"> • When the following conditions are met, the glow control module circuit malfunctions for a continuous 5 s: MONITORING CONDITIONS <ul style="list-style-type: none"> — Battery voltage: 8—20 V — Detects that the output duty value of the glow plug is 10 to 90 % for 1 s or more. Diagnostic support note <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • Inhibits engine-stop by operating the i-stop function.

DTC P0670:00	Glow control module control circuit problem
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Glow control module connector or terminals malfunction • Short to ground or open circuit in glow control module power supply circuit <ul style="list-style-type: none"> — Short to ground in wiring harness between GLOW 80 A fuse and glow control module terminal 2C — GLOW 80 A fuse malfunction — Open circuit in wiring harness between battery positive terminal and glow control module terminal 2C • Short to ground or open circuit in glow control module power supply circuit <ul style="list-style-type: none"> — Short to ground in wiring harness between ENGINE1 15 A fuse and glow control module terminal 2D — ENGINE1 15 A fuse malfunction — Open circuit in wiring harness between main relay terminal C and glow control module terminal 2D • Open circuit in wiring harness between glow control module terminal 2A and body ground <ul style="list-style-type: none"> — GLOW SIG 5 A fuse malfunction (Type B VIN) • Glow plug connector or terminals malfunction • Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> — Glow control module terminal 1B—Glow plug terminal A — Glow control module terminal 1F—Glow plug terminal B — Glow control module terminal 1E—Glow plug terminal C — Glow control module terminal 1A—Glow plug terminal D • Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> — Glow control module terminal 1B—Glow plug terminal A — Glow control module terminal 1F—Glow plug terminal B — Glow control module terminal 1E—Glow plug terminal C — Glow control module terminal 1A—Glow plug terminal D • Glow plug circuits are shorted to each other • PCM connector or terminals malfunction • Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> — Glow control module terminal 2B—PCM terminal 2I — Glow control module terminal 2E—PCM terminal 2BA • Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> — Glow control module terminal 2B—PCM terminal 2I — Glow control module terminal 2E—PCM terminal 2BA • Glow control module circuits are shorted to each other • Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> — Glow control module terminal 2B—PCM terminal 2I — Glow control module terminal 2E—PCM terminal 2BA • Glow control module temperature is too high (more than 125 °C {257 °F}) • Glow control module malfunction • PCM malfunction

DTC
P0670:00

Glow control module control circuit problem



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	INSPECT GLOW CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the glow control module connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 18.
		No	Go to the next step.
5	INSPECT GLOW CONTROL MODULE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the glow control module connector is disconnected. • Measure the voltage at the glow control module terminal 2C (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the GLOW 80 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 18.
6	INSPECT GLOW CONTROL MODULE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the glow control module connector is disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the glow control module terminal 2D (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE1 15 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 18.
7	INSPECT GLOW CONTROL MODULE GROUND CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the glow control module connector is disconnected. • Switch the ignition off. • Inspect for continuity between glow control module terminal 2A (wiring harness-side) and body ground. • Is there continuity? 	Yes	Go to the next step.
		No	Type A VIN: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible open circuit, then go to Step 18. Type B VIN: <ul style="list-style-type: none"> • Inspect the GLOW SIG 5 A fuse. <ul style="list-style-type: none"> — If the fuse is burnt out or deteriorated: <ul style="list-style-type: none"> • Replace the fuse. — If the fuse is normal: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible open circuit. • Go to Step 18.
8	INSPECT GLOW PLUG CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the glow plug connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 18.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
9	INSPECT GLOW PLUG CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the glow control module and glow plug connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Glow plug terminal A — Glow plug terminal B — Glow plug terminal C — Glow plug terminal D • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 18.
		No	Go to the next step.
10	INSPECT GLOW PLUG CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the glow control module and glow plug connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Glow plug terminal A — Glow plug terminal B — Glow plug terminal C — Glow plug terminal D • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 18.
11	INSPECT GLOW PLUG CIRCUITS FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the glow control module and glow plug connectors are disconnected. • Switch the ignition off. • Inspect for continuity between glow plug terminals A, B, C and D (wiring harness-side). • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 18.
		No	Go to the next step.
12	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 18.
		No	Go to the next step.
13	INSPECT GLOW CONTROL MODULE CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the glow control module and glow plug and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Glow control module terminal 2B — Glow control module terminal 2E • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 18.
		No	Go to the next step.
14	INSPECT GLOW CONTROL MODULE CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the glow control module and glow plug and PCM connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Glow control module terminal 2B — Glow control module terminal 2E • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 18.
15	INSPECT GLOW CONTROL MODULE CIRCUITS FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the glow control module and glow plug and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between glow control module terminals 2B and 2E (wiring harness-side). • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 18.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
16	INSPECT GLOW CONTROL MODULE CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the glow control module and glow plug and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Glow control module terminal 2B—PCM terminal 2I — Glow control module terminal 2E—PCM terminal 2BA • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 18.
17	INSPECT GLOW CONTROL MODULE <ul style="list-style-type: none"> • Inspect the glow control module. (See GLOW PLUG CONTROL MODULE INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the glow control module, then go to the next step. (See GLOW PLUG CONTROL MODULE REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
18	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
19	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.