


DTC P0A94:00	DC-DC converter control circuit signal error
DETECTION CONDITION	<ul style="list-style-type: none"> Internal malfunction signal from DC-DC converter via front body control module (FBCM) is received.(CAN/LIN communication). Input signal from the DC-DC converter limits the pressure increase time. Input signal from the DC-DC converter does not implement pressure increase after a pressure increase command to the DC-DC converter. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Battery malfunction DC-DC converter connector or terminals malfunction Short to ground or open circuit in DC-DC converter power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between DCDC 50 A fuse and DC-DC converter terminal L DCDC 50 A fuse malfunction Open circuit in wiring harness between battery positive terminal and DC-DC converter terminal L Short to ground in wiring harness between DC-DC converter terminal F and PCM terminal 2P PCM connector or terminals malfunction Short to power supply in wiring harness between DC-DC converter terminal F and PCM terminal 2P Open circuit in wiring harness between DC-DC converter terminal F and PCM terminal 2P DC-DC converter malfunction Front body control module (FBCM) malfunction PCM malfunction



Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes: Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. No: Go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition to off, then to ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	Go to the next step.
3	CONFIRM FRONT BODY CONTROL MODULE (FBCM) DTC <ul style="list-style-type: none"> Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the next step.
4	INSPECT BATTERY <ul style="list-style-type: none"> Switch the ignition to off. Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Recharge or replace the battery, then go to Step 12. (See BATTERY RECHARGING [SKYACTIV-G 2.0].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
5	INSPECT DC-DC CONVERTER CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the DC-DC converter connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
6	INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the DC-DC converter connector is disconnected. Measure the voltage at the DC-DC converter terminal L (wiring harness-side). Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the DCDC 50 A fuse. <ul style="list-style-type: none"> If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the fuse. If the fuse is normal: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible open circuit. Go to Step 12.
7	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the DC-DC converter connector is disconnected. Inspect for continuity between DC-DC converter terminal F (wiring harness-side) and body ground. Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 12.
		No	Go to the next step.
8	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
9	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the DC-DC converter and PCM connectors are disconnected. • Switch the ignition ON (engine off or on). • Measure the voltage at the DC-DC converter terminal F (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 12.
10	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter and PCM connectors are disconnected. • Switch the ignition to off. • Inspect for continuity between DC-DC converter terminal F (wiring harness-side) and PCM terminal 2P (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 12.
11	INSPECT DC-DC CONVERTER <ul style="list-style-type: none"> • Inspect the DC-DC converter. (See DC-DC CONVERTER INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the DC-DC converter, then go to the next step. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
12	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
13	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.