
FUEL CHECK VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0114z7706100

Note

- The fuel check valve cannot be removed as it is integrated with the lower case.

1. Remove the lower case. (See LOWER CASE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)