

### NO.3 BRAKE SYSTEM WARNING LIGHT STAY ON [DYNAMIC STABILITY CONTROL (DSC)]

id0403b2895800

<b>3</b>	<b>Brake system warning lights stay on</b>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• Brake fluid amount is low.</li> <li>• Parking brake does not release.</li> <li>• Parking brake switch or brake fluid level sensor stuck on.</li> <li>• Short to ground in following circuit: <ul style="list-style-type: none"> <li>— Between parking brake switch and instrument cluster</li> <li>— Between brake fluid level sensor and front body control module (FBCM)</li> </ul> </li> <li>• No connection at DSC HU/CM connector (When DSC HU/CM connector comes off, ABS warning light, brake system warning light, TCS/DSC indicator light, and TCS OFF indicator light illuminate.)</li> <li>• DSC HU/CM detected malfunction. (Input and output device malfunction)</li> <li>• DSC HU/CM detects low voltage in power supply.</li> <li>• DSC HU/CM ground malfunction (When DSC HU/CM ground is not securely connected, ABS warning light, brake system warning light, TCS/DSC indicator light, and TCS OFF indicator light illuminate but diagnostic trouble code does not display.)</li> <li>• DSC HU/CM does not operate.</li> <li>• Front body control module (FBCM) detected malfunction.</li> <li>• DSC HU/CM internal malfunction</li> <li>• Instrument cluster detected malfunction</li> </ul>

#### Diagnostic procedure

STEP	INSPECTION	ACTION
1	<b>INSPECT BRAKE FLUID AMOUNT AND VERIFY THAT PARKING BRAKE RELEASED</b> <ul style="list-style-type: none"> <li>• Inspect the brake fluid amount and verify that the parking brake released.</li> <li>• Is the brake fluid amount normal?</li> <li>• Is the parking brake lever released?</li> </ul>	Yes Go to the next step.
		No Add the brake fluid or release the parking brake lever. If the brake fluid refilled: • Inspect and repair the brake line for leakage.
2	<b>CONFIRM DSC HU/CM DTC</b> <ul style="list-style-type: none"> <li>• Retrieve the DSC HU/CM DTC using the M-MDS (IDS). (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)</li> <li>• Are any DTCs present?</li> </ul>	Yes Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)
		No If communication error message is displayed on the M-MDS (IDS) screen: • Go to the next step. If communication error message is not displayed: • Go to Step 4.
3	<b>INSPECT CONNECTION OF DSC HU/CM CONNECTOR</b> <ul style="list-style-type: none"> <li>• Inspect for connection of the DSC HU/CM connector.</li> <li>• Is the DSC HU/CM connector connected securely?</li> </ul>	Yes Go to the next step.
		No Connect the DSC HU/CM connector securely, then go to the next step.
4	<b>CONFIRM INSTRUMENT CLUSTER OPERATION RECORD</b> <ul style="list-style-type: none"> <li>• Retrieve the warning system operation history using the M-MDS (IDS). (See INSTRUMENT CLUSTER OPERATION RECORD.)</li> <li>• Is the brake system warning light illumination history recorded?</li> </ul>	Yes If the Brake Warning Lamp recorded: • Go to Step 5. If the Brake Warning Lamp (Brake fluid low) recorded: • Go to Step 6. If the Brake Warning Lamp (Parking Brake ON over 20 km/h or 12.4 mile/h) recorded: • Go to Step 8.
		No Go to Step 10.
5	<b>VERIFY WHETHER MALFUNCTION IS IN INSTRUMENT CLUSTER OR ELSEWHERE</b> <ul style="list-style-type: none"> <li>• Connect the M-MDS (IDS) to the DLC-2.</li> <li>• Turn off and on all warning light and indicator lights using the instrument cluster PID WL+IL of active command modes. (See ACTIVE COMMAND MODES INSPECTION [INSTRUMENT CLUSTER].)</li> <li>• Do the ABS warning light, brake system warning light, TCS/DSC indicator light and DSC OFF indicator light turn on and off according to the active command modes?</li> </ul>	Yes Go to Step 10.
		No Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)

STEP	INSPECTION	ACTION	
6	<b>INSPECT WHETHER MALFUNCTION IS IN BRAKE FLUID LEVEL SENSOR OR ELSEWHERE</b> <ul style="list-style-type: none"> <li>Inspect the brake fluid level sensor for continuity. (See BRAKE FLUID LEVEL SENSOR INSPECTION.)</li> <li>Is the continuity condition normal?</li> </ul>	Yes	Go to the next step.
		No	Replace the malfunctioning part. (See MASTER CYLINDER REMOVAL/INSTALLATION.)
*7	<b>INSPECT FOR SHORT TO GROUND IN WIRING HARNESS BETWEEN FRONT BODY CONTROL MODULE (FBCM) AND BRAKE FLUID LEVEL SWITCH</b> <ul style="list-style-type: none"> <li>Inspect for short to ground in the following circuit: <ul style="list-style-type: none"> <li>Between brake fluid level switch and front body control module (FBCM) terminal 2Q</li> </ul> </li> <li>Is the short to ground detected?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to ground.
		No	Retrieve the front body control module (FBCM) DTC using the M-MDS (IDS). (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) If the DTC remains: <ul style="list-style-type: none"> <li>Go to the applicable DTC inspection. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)</li> </ul> If the DTC does not remain: <ul style="list-style-type: none"> <li>Replace the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)</li> </ul>
8	<b>INSPECT WHETHER MALFUNCTION IS IN PARKING BRAKE SWITCH OR ELSEWHERE</b> <ul style="list-style-type: none"> <li>Inspect the following parts for continuity: <ul style="list-style-type: none"> <li>Parking brake switch (See PARKING BRAKE SWITCH INSPECTION.)</li> </ul> </li> <li>Is the continuity condition normal?</li> </ul>	Yes	Go to the next step.
		No	Replace the malfunctioning part. (See PARKING BRAKE LEVER REMOVAL/INSTALLATION.)
*9	<b>INSPECT FOR SHORT TO GROUND IN WIRING HARNESS BETWEEN INSTRUMENT CLUSTER AND PARKING BRAKE SWITCH</b> <ul style="list-style-type: none"> <li>Inspect for short to ground in the following circuit: <ul style="list-style-type: none"> <li>Between parking brake switch and instrument cluster terminal 2X</li> </ul> </li> <li>Is the short to ground detected?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to ground.
		No	Retrieve the instrument cluster DTC using the M-MDS (IDS). (See DTC INSPECTION [INSTRUMENT CLUSTER].) If the DTC remains: <ul style="list-style-type: none"> <li>Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)</li> </ul> If the DTC does not remain: <ul style="list-style-type: none"> <li>Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)</li> </ul>
10	<b>INSPECT DSC HU/CM POWER SUPPLY FUSE</b> <ul style="list-style-type: none"> <li>Inspect the DSC HU/CM ignition power supply fuse.</li> <li>Is the fuse normal?</li> </ul>	Yes	Go to the next step.
		No	Inspect the blown fuse's circuit for short to ground. Repair or replace the wiring harness for a possible short to ground as necessary. Install appropriate amperage fuse.
*11	<b>VERIFY WHETHER MALFUNCTION IS IN WIRING HARNESS (BETWEEN DSC HU/CM POWER SUPPLY AND DSC HU/CM FOR CONTINUITY) OR ELSEWHERE</b> <ul style="list-style-type: none"> <li>Switch the ignition to ON.</li> <li>Measure the voltage at the DSC HU/CM terminal Q (wiring harness-side).</li> <li>Is the voltage <b>approx. 12 V</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect for open circuit between DSC HU/CM and ignition. Repair or replace the wiring harness for a possible open circuit as necessary.
*12	<b>VERIFY WHETHER MALFUNCTION IS IN WIRING HARNESS (BETWEEN DSC HU/CM AND GROUND FOR CONTINUITY) OR ELSEWHERE</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the DSC HU/CM connector.</li> <li>Inspect for continuity between DSC HU/CM terminal AL (wiring harness-side) and body ground.</li> <li>Is there continuity?</li> </ul>	Yes	Replace the DSC HU/CM. (open circuit in the DSC HU/CM) (See DSC HU/CM REMOVAL/INSTALLATION.)
		No	Repair or replace the wiring harness for a possible open circuit and poor contact in ground point.

- 
- When performing an asterisked (\*) troubleshooting inspection, shake the wiring harness and connectors while doing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harness are connected correctly and undamaged.