

**DTC U3000:16/U3000:1C/U3000:28/U3000:41/U3000:46/U3000:47/U3000:49/U3000:61/U3000:73/U3000:96**

id060200813600

<b>DTC U3000:16, U3000:1C, U3000:28, U3000:41, U3000:46, U3000:47, U3000:49, U3000:61, U3000:73, U3000:96</b>	<b>EPS CM</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"><li>• The on-board diagnostic function detects control module malfunction</li></ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"><li>• U3000:16, U3000:1C, U3000:28, U3000:41, U3000:47, U3000:49, U3000:61, U3000:73, U3000:96<ul style="list-style-type: none"><li>• Control disabled</li><li>• Power steering malfunction indicator light: Illuminated</li></ul></li><li>• U3000:46<ul style="list-style-type: none"><li>• Control is maintained in fail mode</li><li>• Power steering malfunction indicator light: Not illuminated</li></ul></li></ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Internal malfunction of EPS CM</li></ul>
<b>SYSTEM WIRING DIAGRAM</b>	—

**Diagnostic Procedure**

<b>Step</b>	<b>Inspection</b>	<b>Action</b>
1	<b>VERIFY DTC</b> <ul style="list-style-type: none"><li>• Clear the DTC from the memory. (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.)</li><li>• Verify if any DTCs are displayed. (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.)</li><li>• Is the same DTC present?</li></ul>	Yes Replace the EPS CM. (See STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION.)
		No Go to the next step.
2	<b>VERIFY THAT NO OTHER DTCs ARE PRESENT</b> <ul style="list-style-type: none"><li>• Are any other DTCs output? (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.)</li></ul>	Yes Go to the applicable DTC inspection. (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.)
		No DTC troubleshooting completed.