

ENGINE OIL SOLENOID VALVE [SKYACTIV-D 2.2]


id0111s6002700

Purpose, Function

- The engine oil solenoid valve switches the hydraulic transmission passage in accordance with the driving conditions and the oil pump drive resistance is reduced by controlling oil pump discharging pressure in two steps.


Construction

- The engine oil solenoid valve is installed on the right side of the cylinder block.



ac5wzn00001852


- The engine oil solenoid valve has the following parts:



ac5wzn00002038

Operation

- The oil passage in the solenoid valve is switched according to the control signal (duty signal) from the PCM.



ac5wzn00002039

Fail-safe

- Function not equipped.