

**Caution**

- Vehicle specifications differ depending on the vehicle identification number (VIN).

- Type A VIN:

- JM0 KE\*\*\*\*\* 100001—

- JM6 KE\*\*\*\*\* 100001—

- JM7 KE\*\*\*\*\* 100001—

- JM8 KE\*\*\*\*\* 100001—

- JMZ KE\*\*\*\*\* 100001—

- KE10\*\* 100001—

- Type B VIN:

- JM0 KE\*\*\*\*\* 200001—

- JM6 KE\*\*\*\*\* 200001—

- JM8 KE\*\*\*\*\* 200001—

- JMZ KE\*\*\*\*\* 200001—

- KE10\*\* 200001—

**Purpose/Function**

- If a transaxle malfunction is detected by the malfunction detection function, the fail-safe function limits the transaxle control.
- Even if the transaxle has a malfunction, the fail-safe function assures the minimum vehicle driveability.

**Construction/Operation****DTC separate fail-safe function**

Type A VIN  
—: Not applicable

DTC No.	Description	Fail-safe function
P0218:00	Automatic transaxle protection control	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits manual mode.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> <li>Inhibits AAS.</li> </ul>
P0500:00	Vehicle speed signal circuit malfunction	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> <li>Inhibits AAS.</li> </ul>
P0666:00	ECU internal temperature sensor circuit(s) malfunction	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> </ul>
P0667:00	ECU internal temperature sensor two-range/performance problem	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> </ul>
P06B8:00	NVRAM malfunction	—
P0706:00	Transaxle range sensor range/performance problem	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits manual mode.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> <li>Inhibits AAS.</li> </ul>
P0707:00	Transaxle range sensor circuit low input	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits manual mode.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> <li>Inhibits AAS.</li> </ul>
P0708:00	Transaxle range sensor circuit high input	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits manual mode.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> <li>Inhibits AAS.</li> </ul>
P0711:00	TFT sensor range/performance problem	<ul style="list-style-type: none"> <li>Inhibits learning control.</li> <li>Inhibits neutral idle control.</li> <li>Inhibits i-stop control.</li> </ul>

DTC No.	Description	Fail-safe function
P0712:00	TFT sensor circuit low input	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P0713:00	TFT sensor circuit high input	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P0716:00	Turbine/input shaft speed sensor range/performance problem	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
P0717:00	Open circuit in turbine/input shaft speed sensor circuit	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
P0721:00	Output shaft speed sensor/sensor output range malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0722:00	Open circuit in output shaft speed sensor circuit	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0729:00	6GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0731:00	1GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0732:00	2GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0733:00	3GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P0734:00	4GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0735:00	5GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0736:00	Gear reverse incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P0741:00	TCC control solenoid stuck off	<ul style="list-style-type: none"> <li>• Inhibits TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0743:00	TCC control solenoid circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0746:00	Pressure control solenoid stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0748:00	Pressure control solenoid circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0751:00	Shift solenoid No.1 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0752:00	Shift solenoid No.1 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0753:00	Shift solenoid No.1 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P0756:00	Shift solenoid No.2 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0757:00	Shift solenoid No.2 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0758:00	Shift solenoid No.2 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0761:00	Shift solenoid No.3 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0762:00	Shift solenoid No.3 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0763:00	Shift solenoid No.3 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0766:00	Shift solenoid No.4 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0767:00	Shift solenoid No.4 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0768:00	Shift solenoid No.4 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P0771:00	On/off solenoid stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0772:00	On/off solenoid stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0773:00	On/off solenoid circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0780:00	Gear shifting malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P079A:00	Shift solenoid No.3 stuck off/On/off solenoid stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0819:00	M position switch/Up switch/Down switch signal error	<ul style="list-style-type: none"> <li>• Inhibits manual mode.</li> </ul>
P0842:00	Oil pressure switch No.1 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0843:00	Oil pressure switch No.1 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0847:00	Oil pressure switch No.2 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0848:00	Oil pressure switch No.2 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P0872:00	Oil pressure switch No.3 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0873:00	Oil pressure switch No.3 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0877:00	Oil pressure switch No.4 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0878:00	Oil pressure switch No.4 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0882:00	TCM power supply voltage low	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0883:00	TCM power supply voltage high	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0C2C:00	Electric AT oil pump rotation malfunction	<ul style="list-style-type: none"> <li>• Inhibits i-stop control.</li> </ul>
P1728:00	Clutch slippage	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Maximizes the line pressure.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P1738:00	Automatic transaxle internal malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P1784:00	Hi cut valve stuck off/R-3-5 cut valve stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P181F:00	Electric AT oil pump/Electric AT oil pump relay circuit malfunction	<ul style="list-style-type: none"> <li>• Inhibits i-stop control.</li> </ul>
P2530:00	Ignition switch stuck off	—
P2712:00	Oil pump shift valve stuck	<ul style="list-style-type: none"> <li>• Inhibits i-stop control.</li> </ul>

DTC No.	Description	Fail-safe function
U0073:00	CAN system communication error (HS CAN)	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
U0074:00	CAN system communication error (local CAN between TCM and PCM)	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
U0100:00	Communication error to PCM (HS CAN)	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
U0115:00	Communication error to PCM (local CAN between TCM and PCM)	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
U0121:00	Communication error to DSC HU/CM	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
U0131:00	Communication error to EPS control module	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
U0155:00	Communication error to instrument cluster	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
U0442:00	Invalid data received from PCM (local CAN between TCM and PCM)	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>

Type B VIN  
—: Not applicable

DTC No.	Description	Fail-safe function
P0218:00	Automatic transaxle protection control	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0500:00	Vehicle speed signal circuit malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0666:00	ECU internal temperature sensor circuit malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P0667:00	ECU internal temperature sensor/performance problem	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P06B8:00	NVRAM malfunction	—

DTC No.	Description	Fail-safe function
P0706:00	Transaxle range sensor range/performance problem	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0707:00	Transaxle range sensor circuit low input	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0708:00	Transaxle range sensor circuit high input	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0711:00	TFT sensor range/performance problem	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P0712:00	TFT sensor circuit low input	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P0713:00	TFT sensor circuit high input	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P0715:00	Turbine/input shaft speed sensor/sensor output range malfunction	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
P0716:00	Turbine/input shaft speed sensor range/performance problem	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
P0717:00	Open circuit in turbine/input shaft speed sensor circuit	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
P0720:00	Output shaft speed sensor range/performance problem	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0721:00	Output shaft speed sensor/sensor output range malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0722:00	Open circuit in output shaft speed sensor circuit	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>



DTC No.	Description	Fail-safe function
P0729:00	6GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0731:00	1GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0732:00	2GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0733:00	3GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0734:00	4GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0735:00	5GR incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0736:00	Gear reverse incorrect ratio	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P073D:00	Neutral incorrect ratio	—
P0741:00	TCC control solenoid stuck off	<ul style="list-style-type: none"> <li>• Inhibits TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0743:00	TCC control solenoid circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P0746:00	Pressure control solenoid stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0748:00	Pressure control solenoid circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0751:00	Shift solenoid No.1 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0752:00	Shift solenoid No.1 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0753:00	Shift solenoid No.1 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0756:00	Shift solenoid No.2 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0757:00	Shift solenoid No.2 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0758:00	Shift solenoid No.2 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0761:00	Shift solenoid No.3 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P0762:00	Shift solenoid No.3 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0763:00	Shift solenoid No.3 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0766:00	Shift solenoid No.4 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0767:00	Shift solenoid No.4 stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0768:00	Shift solenoid No.4 circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0771:00	On/off solenoid stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0772:00	On/off solenoid stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0773:00	On/off solenoid circuit malfunction	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0780:00	Gear shifting malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P079A:00	Shift solenoid No.3 stuck off/On/off solenoid stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0819:00	M position switch/Up switch/Down switch signal error	<ul style="list-style-type: none"> <li>• Inhibits manual mode.</li> </ul>
P0842:00	Oil pressure switch No.1 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0843:00	Oil pressure switch No.1 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0847:00	Oil pressure switch No.2 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0848:00	Oil pressure switch No.2 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0872:00	Oil pressure switch No.3 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0873:00	Oil pressure switch No.3 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0877:00	Oil pressure switch No.4 stuck on	<ul style="list-style-type: none"> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0878:00	Oil pressure switch No.4 stuck off	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>

DTC No.	Description	Fail-safe function
P0882:00	TCM power supply voltage low	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0883:00	TCM power supply voltage high	<ul style="list-style-type: none"> <li>• Set to emergency mode.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P0C2C:00	Electric AT oil pump rotation malfunction	<ul style="list-style-type: none"> <li>• Inhibits i-stop control.</li> </ul>
P1728:00	Clutch slippage	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Maximizes the line pressure.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P1738:00	Automatic transaxle internal malfunction	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
P1784:00	Hi cut valve stuck off/R-3-5 cut valve stuck on	<ul style="list-style-type: none"> <li>• Inhibits malfunctioning gear.</li> <li>• Limits engine torque.</li> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
P181F:00	Electric AT oil pump/Electric AT oil pump relay circuit malfunction	<ul style="list-style-type: none"> <li>• Inhibits i-stop control.</li> </ul>
P2530:00	Ignition switch stuck off	—
P2712:00	Oil pump shift valve stuck	<ul style="list-style-type: none"> <li>• Inhibits i-stop control.</li> </ul>
U0073:00	CAN system communication error (HS CAN)	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
U0074:00	CAN system communication error (local CAN between TCM and PCM)	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>
U0100:00	Communication error to PCM (HS CAN)	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
U0115:00	Communication error to PCM (local CAN between TCM and PCM)	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>

DTC No.	Description	Fail-safe function
U0121:00	Communication error to DSC HU/CM	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> <li>• Inhibits AAS.</li> </ul>
U0131:00	Communication error to EPS control module	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
U0155:00	Communication error to instrument cluster	<ul style="list-style-type: none"> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits i-stop control.</li> </ul>
U0442:00	Invalid data received from PCM (local CAN between TCM and PCM)	<ul style="list-style-type: none"> <li>• Set to TCC control.</li> <li>• Inhibits learning control.</li> <li>• Inhibits manual mode.</li> <li>• Inhibits neutral idle control.</li> <li>• Inhibits 5GR and 6GR.</li> <li>• Inhibits shift down when the accelerator pedal is depressed.</li> </ul>

### Emergency mode

- The emergency mode is a control for preventing transaxle damage or vehicle inoperability.
- If these modes are set, the TCM output is inhibited. Therefore, all solenoids are turned off and the following conditions occur:
  - When the accelerator pedal is depressed, the engine speed is higher than normal.
  - When N to D position and N to R position are selected, the shift shock is greater than during normal shifting.

### Neutral idle control

- System which automatically switches the transaxle to neutral internally while the vehicle is stopped in the D position.