
FUEL PRESSURE RELIEF VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0114z7706500

Note

- The fuel pressure relief valve cannot be removed as it is integrated with the common rail.

1. Remove the common rail. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)