

# **DTC P06B8:00 [SKYACTIV-G 2.0]**

id0102h1316200

<b>DTC P06B8:00</b>	<b>Internal control module non-volatile RAM error</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>• PCM internal EEPROM malfunction.</li> </ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"> <li>• This is a continuous monitor (other).</li> <li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>• The DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	—
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• PCM connector or terminals malfunction</li> <li>• PCM internal EEPROM malfunction</li> </ul>
<b>SYSTEM WIRING DIAGRAM</b>	—

## **Diagnostic Procedure**

<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>• Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>• Verify related Service Information availability.</li> <li>• Is any related Service Information available?</li> </ul>	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition to off.</li> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes Repair or replace the connector and/or terminals, then go to the next step.
		No Go to the next step.
4	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Make sure to reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].)</li> <li>• Is the same DTC present?</li> </ul>	Yes Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No Go to the next step.
5	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>• Are any DTCs present?</li> </ul>	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No DTC troubleshooting completed.