

DTC P2503:00	Charging system voltage low input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM determines that the generator output voltage is less than 8.5 V, and the generator target output current is more than 20 A, for 5 s while the engine is running. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Illuminates the charging system warning light.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Drive belt exceeds limit Generator connector or terminals malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> Generator terminal 2B—PCM terminal 1BE Generator terminal 2A—PCM terminal 1AF PCM connector or terminals malfunction Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Generator terminal 2B—PCM terminal 1BE Generator terminal 2A—PCM terminal 1AF Generator malfunction PCM malfunction

Diagnostic Procedure

Diagnostic Procedure		
STEP	INSPECTION	ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.

STEP	INSPECTION		ACTION
2	INSPECT DRIVE BELT CONDITION <ul style="list-style-type: none"> • Verify that the drive belt auto tensioner indicator mark does not exceed limit. (See DRIVE BELT INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the drive belt, then go to Step 8. (See DRIVE BELT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
3	INSPECT GENERATOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the generator connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT GENERATOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the generator connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Generator terminal 2B — Generator terminal 2A • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 8.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	INSPECT GENERATOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the generator and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Generator terminal 2B—PCM terminal 1BE — Generator terminal 2A—PCM terminal 1AF • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 8.
7	INSPECT GENERATOR <ul style="list-style-type: none"> • Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step. (See GENERATOR DISASSEMBLY/ASSEMBLY [SKYACTIV-G 2.0].) (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.