

DTC B00D2:01

id080200824000

System malfunction location	• Air bag system warning light malfunction
Detection condition	Warning <ul style="list-style-type: none">• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure. • Air bag system warning light malfunction detected
Fail-safe	—
Possible cause	• Air bag system warning light malfunction
System wiring diagram	—

Diagnostic Procedure

Action
Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)