

Note

- The RVM switch is integrated with the cluster switch.
- For the cluster switch removal/installation, refer to the switch panel removal/installation because the cluster switch is installed to the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)