

<b>DTC P0092:00</b>	<b>Fuel pressure regulator control circuit high input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>When the PCM turns the spill valve control solenoid valve on but the spill valve control solenoid valve circuit voltage is high for <b>5 s</b>, the PCM determines that the spill valve control solenoid valve control circuit has a malfunction.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>The following conditions are met: <ul style="list-style-type: none"> <li>Engine speed: <b>5,700 rpm or less</b></li> <li>Battery voltage: <b>10.5 V or more</b></li> </ul> </li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>The DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Stops the high pressure fuel pump control.</li> <li>Limits the intake air amount.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>High pressure fuel pump connector or terminals malfunction</li> <li>PCM connector or terminals malfunction</li> <li>Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>High pressure fuel pump terminal A—PCM terminal 1EE</li> <li>High pressure fuel pump terminal B—PCM terminal 1EF</li> </ul> </li> <li>Spill valve control solenoid valve (built-into high pressure fuel pump) malfunction</li> <li>PCM malfunction</li> </ul>

⑥

SPILL VALVE CONTROL SOLENOID VALVE  
(HIGH PRESSURE FUEL PUMP)

HIGH PRESSURE FUEL PUMP  
WIRING HARNESS-SIDE  
CONNECTOR

PCM

PCM WIRING HARNESS-SIDE CONNECTOR

## Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>INSPECT HIGH PRESSURE FUEL PUMP CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the high pressure fuel pump connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
4	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	<b>INSPECT SPILL VALVE CONTROL SOLENOID VALVE CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>Verify that the high pressure fuel pump and PCM connectors are disconnected.</li> <li>Switch the ignition ON (engine off or on).</li> <li>Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>High pressure fuel pump terminal A</li> <li>High pressure fuel pump terminal B</li> </ul> </li> <li>Is the voltage <b>0 V</b>?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 7.
6	<b>INSPECT SPILL VALVE CONTROL SOLENOID VALVE</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Reconnect all disconnected connectors.</li> <li>Inspect the spill valve control solenoid valve. (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.0].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the high pressure fuel pump, then go to the next step. (See HIGH PRESSURE FUEL PUMP REMOVAL/ INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
7	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Make sure to reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>Start the engine.</li> <li>Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].)</li> <li>Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
8	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.