

4WD SOLENOID INSPECTION

id031800805800


1. Disconnect the negative battery cable.
2. Disconnect the 4WD solenoid connector.
3. Measure resistance between 4WD solenoid connector terminals A and B.
 - If the resistance is not within the specification, replace the coupling unit.

4WD solenoid resistance

2.2—2.7 ohms

(Rear differential oil temperature at 20°C {68° F})

4. Connect the 4WD solenoid connector.
5. Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)



ac5wzw00002635