

---

**GEAR POSITION INDICATOR ILLUMINATES IN P, R, N AND D POSITIONS [FW6A-EL, FW6AX-EL]**

id050317103500

<b>TROUBLESHOOTING ITEM</b>	<b>Gear position indicator illuminates in P, R, N and D positions</b>
<b>DESCRIPTION</b>	• Gear position indicator in instrument cluster illuminates in P, R, N and D positions with the ignition switched ON (engine off or on).
<b>POSSIBLE CAUSE</b>	1. Instrument cluster malfunction

**Diagnostic procedure**

<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>
1	<b>INSPECT INSTRUMENT CLUSTER FOR MALFUNCTION</b> <ul style="list-style-type: none"><li>Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.)</li><li>Is there any malfunction?</li></ul>	Yes Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)
		No Symptom troubleshooting is completed.