


Caution

- Vehicle specifications differ depending on the vehicle identification number (VIN).
 - Type A VIN:
 - JM0 KE***** 100001—
 - JM6 KE***** 100001—
 - JM8 KE***** 100001—
 - JMZ KE***** 100001—
 - Type B VIN:
 - JM0 KE***** 200001—
 - JM6 KE***** 200001—
 - JM8 KE***** 200001—
 - JMZ KE***** 200001—

DTC P0384:00	Glow control module circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> • The PCM monitors the input current from the glow control module. If the input current is above 5.9 A for 1 s, the PCM determines that the glow control module circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> — Battery voltage: 9—16 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Glow control module connector or terminals malfunction • Open circuit in wiring harness between glow control module terminal 2A and body ground <ul style="list-style-type: none"> — GLOW SIG 5 A fuse malfunction (Type B VIN) • PCM connector or terminals malfunction • Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> — Glow control module terminal 2B—PCM terminal 2I — Glow control module terminal 2E—PCM terminal 2BA • Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> — Glow control module terminal 2B—PCM terminal 2I — Glow control module terminal 2E—PCM terminal 2BA • Glow control module malfunction • PCM malfunction

**DTC
P0384:00**

Glow control module circuit high input



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none">Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT GLOW CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the glow control module connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT GLOW CONTROL MODULE GROUND CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the glow control module connector is disconnected. • Inspect for continuity between glow control module terminal 2A (wiring harness-side) and body ground. • Is there continuity? 	Yes	Go to the next step.
		No	Type A VIN: • Repair or replace the wiring harness for a possible open circuit, then go to Step 9. Type B VIN: • Inspect the GLOW SIG 5 A fuse. — If the fuse is burnt out or deteriorated: • Replace the fuse. — If the fuse is normal: • Repair or replace the wiring harness for a possible open circuit. • Go to Step 9.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	INSPECT GLOW CONTROL MODULE CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the glow control module and PCM connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the following terminals (wiring harness-side): — Glow control module terminal 2B — Glow control module terminal 2E • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 9.
7	INSPECT GLOW CONTROL MODULE CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the glow control module and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between the following terminals (wiring harness-side): — Glow control module terminal 2B—PCM terminal 2I — Glow control module terminal 2E—PCM terminal 2BA • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT GLOW CONTROL MODULE <ul style="list-style-type: none"> • Inspect the glow control module. (See GLOW PLUG CONTROL MODULE REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the glow control module, then go to the next step. (See GLOW PLUG CONTROL MODULE REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.