
DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE

id041500870200

Warning

- If the initialization procedure is not completed, the DSC will not operate properly and it might cause an unexpected accident. Therefore, after replacing or removing the DSC HU/CM or SAS control module, make sure to perform the initialization procedure to insure proper DSC operation.

1. Inspect the wheel alignment and the tire pressure.
 - If there is any malfunction, adjust the applicable part.
2. Position the vehicle on level ground.
3. Switch the ignition to off.
4. Connect the M-MDS (IDS) to DLC-2.
5. After the vehicle is identified, select the following items from the initial screen of the IDS.
 1. Select "Chassis".
 2. Select "ABS/DSC".
 3. Select "Sensor Initialization".
6. Then, select an item from the screen menu.
 - "Brake fluid pressure sensor"
 - "Lateral Acceleration Sensor"
 - "Yaw Rate Sensor"
 - "Longitudinal Acceleration Sensor"
7. Perform the procedure according to the directions on the screen.
8. Drive the vehicle.
9. After **5 min or more** of driving, verify that the DSC system is normal.