

**Caution**

- Vehicle specifications differ depending on the vehicle identification number (VIN).

- Type A VIN:

- JM0 KE\*\*\*\*\* 100001—

- JM6 KE\*\*\*\*\* 100001—

- JM7 KE\*\*\*\*\* 100001—

- JM8 KE\*\*\*\*\* 100001—

- JMZ KE\*\*\*\*\* 100001—

- KE10\*\* 100001—

- Type B VIN:

- JM0 KE\*\*\*\*\* 200001—


- JM6 KE\*\*\*\*\* 200001—

- JM8 KE\*\*\*\*\* 200001—

- JMZ KE\*\*\*\*\* 200001—

- KE10\*\* 200001—

<b>DTC P0628:00</b>	<b>Fuel pump control module circuit low input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>• When the PCM outputs a duty signal to the fuel pump control module, the difference in voltage between fuel pump unit terminals B and D is <b>less than 1.5 V</b> for a continuous <b>5 s</b>.</li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>• This is a continuous monitor (CCM).</li> <li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. (Type A VIN)</li> <li>• The check engine light does not illuminate. (Type B VIN)</li> <li>• FREEZE FRAME DATA (Mode 2) is not available. (Type B VIN)</li> <li>• FREEZE FRAME DATA (Mode 2) is available. (Type A VIN)</li> <li>• Snapshot data is available.</li> <li>• DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	Not applicable
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• Fuel pump unit connector or terminals malfunction</li> <li>• Fuel pump unit malfunction</li> <li>• Fuel pump control module connector or terminals malfunction</li> <li>• Short to ground in wiring harness between fuel pump unit terminal A and fuel pump control module terminal 2C</li> <li>• Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>— Fuel pump unit terminal A—Fuel pump control module terminal 2C</li> <li>— Fuel pump unit terminal B—Fuel pump control module terminal 2D</li> </ul> </li> <li>• Fuel pump control module malfunction</li> <li>• PCM malfunction</li> </ul>



### Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>INSPECT FUEL PUMP UNIT CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the fuel pump unit connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	<b>INSPECT FUEL PUMP UNIT</b> <ul style="list-style-type: none"> <li>Inspect the fuel pump unit. (See FUEL PUMP UNIT INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the fuel pump unit, then go to Step 9. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
5	<b>INSPECT FUEL PUMP CONTROL MODULE CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the fuel pump control module connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
6	<b>INSPECT FUEL PUMP UNIT CONTROL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the fuel pump unit and fuel pump control module connectors are disconnected.</li> <li>• Inspect for continuity between fuel pump unit terminal A (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 9.
		No	Go to the next step.
7	<b>INSPECT FUEL PUMP UNIT CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the fuel pump unit and fuel pump control module connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Fuel pump unit terminal A—Fuel pump control module terminal 2C</li> <li>— Fuel pump unit terminal B—Fuel pump control module terminal 2D</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	<b>INSPECT FUEL PUMP CONTROL MODULE</b> <ul style="list-style-type: none"> <li>• Inspect the fuel pump control module. (See FUEL PUMP CONTROL MODULE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the fuel pump control module, then go to the next step. (See FUEL PUMP CONTROL MODULE REMOVAL/ INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
9	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> </ul> Go to the next step.
		No	Go to the next step.
10	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.