

---

## AUTO LIGHT SENSOR REMOVAL/INSTALLATION

id091800807200

### **Note**

- The auto light sensor is integrated with the rain sensor as a single unit.
- Refer to "RAIN SENSOR REMOVAL/INSTALLATION" to remove the auto light sensor. (See RAIN SENSOR REMOVAL/INSTALLATION.)