


## id051500169900

- 


2WD



6	Funnel
7	Bearing outer race
8	Oil seal (See Oil Seal Assembly Note.)
9	Funnel
10	Oil path


1. Assemble the bearing outer race (differential) to the clutch housing using the **SSTs**.

## 2WD




bc61um00000137

## 4WD



bc62zm00000043


2. Assemble the bearing outer race (differential) to the transaxle case using the **SSTs**.



bc62zm00000044

### Oil Seal Assembly Note

1. Assemble the oil seal using the **SST**.



bc61um00000164