







DTC B13C3:09 [ADVANCED KEYLESS ENTRY SYSTEM]

id0902p8027000

System malfunction location	LF control unit malfunction
Detection condition	<ul style="list-style-type: none"> The start stop unit detects that the LF State signal of the LF control unit is low for 5 s or more. With the communication between the start stop unit and LF control unit being performed normally, there is no response from the LF control unit even though there is a signal transmission request from the start stop unit to the LF control unit, and the LF state signal becomes low.
Fail-safe	<ul style="list-style-type: none"> Inhibits the door lock/unlock control using the advanced keyless entry system.
Possible cause	<ul style="list-style-type: none"> LF control unit connector or terminal malfunction Start stop unit connector or terminal malfunction Short to ground in wiring harness between start stop unit terminal 2H and LF control unit terminal K Open circuit in wiring harness between start stop unit terminal 2H and LF control unit terminal K LF control unit malfunction Start stop unit malfunction
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>START STOP UNIT</p>  <p>START STOP UNIT WIRING HARNESS-SIDE CONNECTOR</p>   </div> <div style="text-align: center;"> <p>LF CONTROL UNIT</p>  <p>LF CONTROL UNIT WIRING HARNESS-SIDE CONNECTOR</p>   </div> </div> <p>The diagram shows a connection line between terminal 2H of the Start Stop Unit and terminal K of the LF Control Unit. Below each unit is a detailed view of its wiring harness-side connector with terminal labels.</p>	

Diagnostic Procedure

Step	Inspection	Action
1	INSPECT LF CONTROL UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Disconnect the LF control unit connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 6.
2	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the start stop unit connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 6.

Step	Inspection	Action	
3	INSPECT LF CONTROL UNIT CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the start stop unit and LF control unit connectors are disconnected. • Inspect for continuity between LF control unit terminal K (vehicle wiring harness side) and body ground. • Is there continuity? 	Yes	Repair or replace the wiring harness which is shorted to ground, then go to Step 6.
		No	Go to the next step.
4	INSPECT LF CONTROL UNIT CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the start stop unit and LF control unit connectors are disconnected. • Inspect the wiring harness for continuity between start stop unit terminal 2H (vehicle wiring harness side) and LF control unit terminal K (vehicle wiring harness side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness which has an open circuit, then go to Step 6.
5	INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> • Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) • Is the LF control unit normal? 	Yes	Go to the next step.
		No	Replace the LF control unit, then go to the next step. (See LF CONTROL UNIT REMOVAL/INSTALLATION.)
6	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear DTCs for the advanced keyless entry system using the M-MDS. (See CLEARING DTC [ADVANCED KEYLESS ENTRY SYSTEM].) • Switch the ignition ON (engine off or on) and wait for 5 s or more. • Perform the advanced keyless entry system DTC inspection using the M-MDS. (See DTC INSPECTION [ADVANCED KEYLESS ENTRY SYSTEM].) • Is DTC B13C3:09 displayed? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.
7	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ADVANCED KEYLESS ENTRY SYSTEM].)
		No	DTC troubleshooting completed.