
EVAPORATOR INSPECTION

id071100801500

1. Inspect the evaporator for damage, cracks, and oil leakage.
 - If there is any malfunction, replace the evaporator.
2. Visually inspect the fins for bending.
 - If there is any bending, use the end of a flathead screwdriver to straighten the fins.