

# DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)]

id0902p2006300

×: Applicable  
—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail- safe function	Drive cycle	Self test type*1	Memory function	Page
B1008:02	—	Windshield wiper control signal mismatch	—	—	C, D	×	(See DTC B1008:02 [FRONT BODY CONTROL MODULE (FBCM)].)
B1008:62	—	Windshield wiper LO switch signal mismatch	—	—	C, D	×	(See DTC B1008:62 [FRONT BODY CONTROL MODULE (FBCM)].)
B1048:7B	—	Brake fluid level sensor circuit malfunction	—	—	C, D	×	(See DTC B1048:7B [FRONT BODY CONTROL MODULE (FBCM)].)
B1087:88	—	LIN communication error	—	—	C, D	×	(See DTC B1087:88 [FRONT BODY CONTROL MODULE (FBCM)].)
B1088:88	—	LIN communication error	—	—	C, D	×	(See DTC B1088:88 [FRONT BODY CONTROL MODULE (FBCM)].)
B1095:72	—	Autostop switch circuit malfunction	—	—	C, D	×	(See DTC B1095:72/ B1095:73 [FRONT BODY CONTROL MODULE (FBCM)].)
B1095:73	—	Autostop switch circuit malfunction	—	—	C, D	×	
B109A:12	—	Headlight HI relay circuit malfunction	—	—	C, D	×	(See DTC B109A:12 [FRONT BODY CONTROL MODULE (FBCM)].)
B109A:14	—	Headlight HI relay circuit malfunction	—	—	C, D	×	(See DTC B109A:14 [FRONT BODY CONTROL MODULE (FBCM)].)
B10A6:64	—	Light switch error signal received	—	—	C, D	×	(See DTC B10A6:64 [FRONT BODY CONTROL MODULE (FBCM)].)
B10A8:12 *2	—	Headlight LO relay circuit malfunction	—	—	C, D	×	(See DTC B10A8:12 [FRONT BODY CONTROL MODULE (FBCM)].)
B10AD: 86*3	—	Error signal received from auto-light sensor/rain sensor	—	—	C, D	×	(See DTC B10AD:86 [FRONT BODY CONTROL MODULE (FBCM)].)
B10AF:12	—	Blower relay circuit malfunction	—	—	C, D	×	(See DTC B10AF:12 [FRONT BODY CONTROL MODULE (FBCM)].)
B1142:13	—	Front body control module (FBCM) power supply voltage (+IG1 power supply) input circuit malfunction	—	—	C, D	×	(See DTC B1142:13 [FRONT BODY CONTROL MODULE (FBCM)].)
B1143:13	—	IG2 power supply control circuit malfunction	—	—	C, D	×	(See DTC B1143:13 [FRONT BODY CONTROL MODULE (FBCM)].)

DTC No.	Warning/ indicator light	Description	Fail- safe function	Drive cycle	Self test type *1	Memory function	Page
B11DB:86	—	Error signal received from current sensor	—	—	C, D	×	(See DTC B11DB:86 [FRONT BODY CONTROL MODULE (FBCM)].)
B1314:11	—	Illumination output circuit malfunction	—	—	C, D	×	(See DTC B1314:11 [FRONT BODY CONTROL MODULE (FBCM)].)
B134D:02	—	Headlight control signal error	—	—	C, D	×	(See DTC B134D:02 [FRONT BODY CONTROL MODULE (FBCM)].)
B13AF:62	—	Headlight LO signal mismatch	—	—	C, D	×	(See DTC B13AF:62 [FRONT BODY CONTROL MODULE (FBCM)].)
B13CF:19	—	IG2 power supply output circuit malfunction	—	—	C, D	×	(See DTC B13CF:19 [FRONT BODY CONTROL MODULE (FBCM)].)
B13D0:11	—	TNS circuit malfunction	—	—	C, D	×	(See DTC B13D0:11 [FRONT BODY CONTROL MODULE (FBCM)].)
B13D2:12 *4	—	Front fog light relay circuit malfunction	—	—	C, D	×	(See DTC B13D2:12 [FRONT BODY CONTROL MODULE (FBCM)].)
B13FE: 12*5	—	Headlight LO relay (RH) circuit malfunction	—	—	C, D	×	(See DTC B13FE:12 [FRONT BODY CONTROL MODULE (FBCM)].)
B13FE: 14*5	—	Headlight LO relay (RH) circuit malfunction	—	—	C, D	×	(See DTC B13FE:14 [FRONT BODY CONTROL MODULE (FBCM)].)
B141E: 12*5	—	Headlight LO relay (LH) circuit malfunction	—	—	C, D	×	(See DTC B141E:12 [FRONT BODY CONTROL MODULE (FBCM)].)
B1C79:97	—	Washer motor switch circuit malfunction	—	—	C, D	×	(See DTC B1C79:97 [FRONT BODY CONTROL MODULE (FBCM)].)
B1C82:97 *6	—	Headlight cleaner motor switch circuit malfunction	—	—	C, D	×	(See DTC B1C82:97 [FRONT BODY CONTROL MODULE (FBCM)].)
B1C84:12	—	Rear window defroster circuit malfunction	—	—	C, D	×	(See DTC B1C84:12 [FRONT BODY CONTROL MODULE (FBCM)].)
B1C84:14	—	Rear window defroster circuit malfunction	—	—	C, D	×	(See DTC B1C84:14 [FRONT BODY CONTROL MODULE (FBCM)].)
B1D06:11	—	Turn light (LH) circuit malfunction	—	—	C, D	×	(See DTC B1D06:11 [FRONT BODY CONTROL MODULE (FBCM)].)

DTC No.	Warning/ indicator light	Description	Fail- safe function	Drive cycle	Self test type*1	Memory function	Page
B1D06:13	—	Turn light (LH) circuit malfunction	—	—	C, D	×	(See DTC B1D06:13 [FRONT BODY CONTROL MODULE (FBCM)].)
B1D07:11	—	Turn light (RH) circuit malfunction	—	—	C, D	×	(See DTC B1D07:11 [FRONT BODY CONTROL MODULE (FBCM)].)
B1D07:13	—	Turn light (RH) circuit malfunction	—	—	C, D	×	(See DTC B1D07:13 [FRONT BODY CONTROL MODULE (FBCM)].)
C1126:11	—	Parking light (LH/RH) circuit malfunction	—	—	C, D	×	(See DTC C1126:11 [FRONT BODY CONTROL MODULE (FBCM)].)
C1126:13	—	Parking light (LH/RH) circuit malfunction	—	—	C, D	×	(See DTC C1126:13 [FRONT BODY CONTROL MODULE (FBCM)].)
U0001:88	—	Module communication error (HS- CAN)	×	—	C, D	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0151:00/ U0155:00/U0214:00/ U023A:00/U0515:00 [FRONT BODY CONTROL MODULE (FBCM)].)
U0100:00	—	Communication error with PCM	×	—	C, D	×	
U0101:00 *7	—	Communication error with TCM	×	—	C, D	×	
U0121:00	—	Communication error with DSC HU/CM	×	—	C, D	×	
U0151:00 *10	—	SAS control module communication error	×	—	C, D	×	
U0155:00	—	Communication error with instrument cluster	×	—	C, D	×	
U0164:68 *8	—	Communication error between climate control unit	—	—	C, D	×	(See DTC U0164:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U0214:00	—	Communication error with start stop unit	×	—	C, D	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0151:00/ U0155:00/U0214:00/ U023A:00/U0515:00 [FRONT BODY CONTROL MODULE (FBCM)].)
U0231:68 *3	—	Communication error with auto- light sensor/rain sensor	—	—	C, D	×	(See DTC U0231:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U023A: 00*9	—	Communication error with forward sensing camera (FSC)	×	—	C, D	×	(See DTC U0001:88/ U0100:00/U0101:00/ U0121:00/U0151:00/ U0155:00/U0214:00/ U023A:00/U0515:00 [FRONT BODY CONTROL MODULE (FBCM)].)
U0298:68	—	Communication error with DC-DC converter	—	—	C, D	×	(See DTC U0298:68 [FRONT BODY CONTROL MODULE (FBCM)].)

DTC No.	Warning/ indicator light	Description	Fail- safe function	Drive cycle	Self test type *1	Memory function	Page
U0338:09	—	Error light switch signal received from start stop unit	—	—	C, D	×	(See DTC U0338:09 [FRONT BODY CONTROL MODULE (FBCM)].)
U0401:68	—	Error signal received from PCM	—	—	C, D	×	(See DTC U0401:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U0415:68	—	Error signal received from DSC HU/CM	—	—	C, D	×	(See DTC U0415:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U053B:68*9	—	Error signal received from forward sensing camera (FSC)	—	—	C, D	×	(See DTC U053B:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U0515:00*10	—	SAS control module communication error	×	—	C, D	×	(See DTC U0001:88/U0100:00/U0101:00/U0121:00/U0151:00/U0155:00/U0214:00/U023A:00/U0515:00 [FRONT BODY CONTROL MODULE (FBCM)].)
U0599:68	—	Error signal received from DC-DC converter	—	—	C, D	×	(See DTC U0599:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U1007:68	—	Communication error with current sensor	—	—	C, D	×	(See DTC U1007:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U2005:68	—	Error vehicle speed signal received from PCM	—	—	C, D	×	(See DTC U2005:68 [FRONT BODY CONTROL MODULE (FBCM)].)
U2100:00	—	Front body control module (FBCM) configuration error	—	—	C, D	×	(See DTC U2100:00 [FRONT BODY CONTROL MODULE (FBCM)].)
U2101:00	—	Front body control module (FBCM) configuration error	—	—	C, D	×	(See DTC U2101:00 [FRONT BODY CONTROL MODULE (FBCM)].)
U3000:49	—	Front body control module (FBCM) internal malfunction	—	—	C, D	×	(See DTC U3000:49 [FRONT BODY CONTROL MODULE (FBCM)].)
U3000:56	—	Front body control module (FBCM) configuration error	—	—	C, D	×	(See DTC U3000:56 [FRONT BODY CONTROL MODULE (FBCM)].)
U3003:16	—	Front body control module (FBCM) power supply voltage (+B power supply) low input	—	—	C, D	×	(See DTC U3003:16 [FRONT BODY CONTROL MODULE (FBCM)].)
U3003:17	—	Front body control module (FBCM) power supply voltage (+B power supply) high input	—	—	C, D	×	(See DTC U3003:17 [FRONT BODY CONTROL MODULE (FBCM)].)

DTC No.	Warning/ indicator light	Description	Fail- safe function	Drive cycle	Self test type*1	Memory function	Page
U3006:62	—	Front body control module (FBCM) power supply voltage mismatch	—	—	C, D	×	(See DTC U3006:62 [FRONT BODY CONTROL MODULE (FBCM)].)

\*1 : C: CMDTC self test, D: ODDTC self test

\*2 : With headlights (halogen type)

\*3 : With auto-light sensor

\*4 : With front fog lights

\*5 : With headlights (discharge type)

\*6 : With headlight cleaner

\*7 : ATX

\*8 : With manual A/C

\*9 : With forward sensing camera (FSC)

\*10 : Some vehicles are not displayed depending on vehicle's period of manufacture