


# DTC P0653:00 [SKYACTIV-D 2.2]

id0102s4065300

<b>DTC P0653:00</b>	<b>Constant voltage power supply control circuit high input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>When the following condition is met, the output voltage of the <b>5 V</b> power supply terminal <b>exceeds 4.1 V</b> for a continuous <b>1 s</b>:  <b>MONITORING CONDITIONS</b> <ul style="list-style-type: none"> <li>Battery voltage: <b>8—20 V</b></li> </ul> </li> <li><b>Diagnostic support note</b></li> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Inhibits the EGR control.</li> <li>Inhibits engine-stop by operating the i-stop function.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>APP sensor connector or terminals malfunction</li> <li>CMP sensor connector or terminals malfunction</li> <li>EGR cooler bypass valve/EGR cooler bypass valve position sensor connector or terminals malfunction</li> <li>EGR valve/EGR valve position sensor connector or terminals malfunction</li> <li>Intake shutter valve/intake shutter valve position sensor connector or terminals malfunction</li> <li>Exhaust gas pressure sensor No.1 connector or terminals malfunction</li> <li>Exhaust gas pressure sensor No.2 connector or terminals malfunction</li> <li>MAP sensor No.1 connector or terminals malfunction</li> <li>Fuel pressure sensor connector or terminals malfunction</li> <li>PCM connector or terminals malfunction</li> <li>Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>APP sensor terminal A—PCM terminal 2AM</li> <li>CMP sensor terminal C—PCM terminal 1K</li> <li>EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal B—PCM terminal 1AU</li> <li>EGR valve/EGR valve position sensor terminal B—PCM terminal 1AP</li> <li>Intake shutter valve/intake shutter valve position sensor terminal E—PCM terminal 1AZ</li> <li>Exhaust gas pressure sensor No.1 terminal C—PCM terminal 1CJ</li> <li>Exhaust gas pressure sensor No.2 terminal A—PCM terminal 1AK</li> <li>MAP sensor No.1 terminal A—PCM terminal 1BJ</li> <li>Fuel pressure sensor terminal C—PCM terminal 1AR</li> </ul> </li> <li>PCM malfunction</li> </ul>

**DTC  
P0653:00**

**Constant voltage power supply control circuit high input**



## Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Information availability.</li> <li>Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> <ul style="list-style-type: none"> <li>Switch the ignition off, then ON (engine off).</li> <li>Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>Are any other PENDING CODEs and/or DTCs present?</li> </ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	<b>INSPECT APP SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the APP sensor connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
5	<b>INSPECT CMP SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the CMP sensor connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
6	<b>INSPECT EGR COOLER BYPASS VALVE/EGR COOLER BYPASS VALVE POSITION SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the EGR cooler bypass valve/EGR cooler bypass valve position sensor connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
7	<b>INSPECT EGR VALVE/EGR VALVE POSITION SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the EGR valve/EGR valve position sensor connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
8	<b>INSPECT INTAKE SHUTTER VALVE/INTAKE SHUTTER VALVE POSITION SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the intake shutter valve/intake shutter valve position sensor connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
9	<b>INSPECT EXHAUST GAS PRESSURE SENSOR NO.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the exhaust gas pressure sensor No. 1 connector.</li> <li>Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
10	<b>INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the exhaust gas pressure sensor No. 2 connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
11	<b>INSPECT MAP SENSOR NO.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the MAP sensor No.1 connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
12	<b>INSPECT FUEL PRESSURE SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the fuel pressure sensor connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
13	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/ pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
14	<b>INSPECT EACH POWER CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the APP sensor, CMP sensor, EGR cooler bypass valve/EGR cooler bypass valve position sensor, EGR valve/EGR valve position sensor, intake shutter valve/intake shutter valve position sensor, exhaust gas pressure sensor No. 1, exhaust gas pressure sensor No.2, MAP sensor No.1, fuel pressure sensor and PCM connectors are disconnected.</li> <li>• Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— APP sensor terminal A</li> <li>— CMP sensor terminal C</li> <li>— EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal B</li> <li>— EGR valve/EGR valve position sensor terminal B</li> <li>— Intake shutter valve/intake shutter valve position sensor terminal E</li> <li>— Exhaust gas pressure sensor No.1 terminal C</li> <li>— Exhaust gas pressure sensor No.2 terminal A</li> <li>— MAP sensor No.1 terminal A</li> <li>— Fuel pressure sensor terminal C</li> </ul> </li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
15	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>• Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.

---

STEP	INSPECTION		ACTION
16	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.