


DTC U3003:16 [FRONT BODY CONTROL MODULE (FBCM)]

id0902p2011600

System malfunction location	Front body control module (FBCM) power supply voltage (+B power supply) low input
Detection condition	<ul style="list-style-type: none"> • Front body control module (FBCM) power supply circuit voltage of 8.8 V or less is detected for 10 s or more with the ignition switched ON (engine off or on).
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> • DTCs are stored in the PCM. • Battery malfunction • Generator malfunction • Front body control module (FBCM) connector or terminal malfunction • Front body control module (FBCM) power supply circuit malfunction <ul style="list-style-type: none"> — Short to ground in the wiring harness between ROOM 15 A fuse and front body control module (FBCM) terminal 2A — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 1A — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 1B — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 3K — Short to ground in the wiring harness between HAZARD 25 A fuse and front body control module (FBCM) terminal 3L — ROOM 15 A fuse malfunction — HAZARD 25 A fuse malfunction — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 2A — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 1A — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 1B — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 3K — Open circuit in wiring harness between battery positive terminal and front body control module (FBCM) terminal 3L • Front body control module (FBCM) malfunction



Diagnostic Procedure

Step	Inspection	Action
1	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs AGAIN <ul style="list-style-type: none"> Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) Switch the ignition ON (engine off or on) and wait for 10 s or more. Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Is DTC U3003:16 displayed? 	<div style="display: flex; justify-content: space-between;"> <div>Yes</div> <div>Go to the next step.</div> </div> <div style="display: flex; justify-content: space-between;"> <div>No</div> <div>Go to Step 8.</div> </div>

Step	Inspection	Action
2	VERIFY PCM DTCs <ul style="list-style-type: none"> Perform the DTC inspection for the PCM using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Is the DTC displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC TABLE [SKYACTIV-D 2.2].)
		No Go to the next step.
3	INSPECT BATTERY <ul style="list-style-type: none"> Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See BATTERY INSPECTION [SKYACTIV-D 2.2].) Is the battery normal? 	Yes Go to the next step.
		No Recharge or replace the battery, then go to Step 7. (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY RECHARGING [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See BATTERY RECHARGING [SKYACTIV-D 2.2].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
4	INSPECT GENERATOR <ul style="list-style-type: none"> Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See GENERATOR INSPECTION [SKYACTIV-D 2.2].) Is the generator normal? 	Yes Go to the next step.
		No Replace the generator, then go to Step 7. (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
5	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Disconnect the front body control module (FBCM) connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 7.

Step	Inspection	Action
6	VERIFY FRONT BODY CONTROL MODULE (FBCM) POWER SUPPLY VOLTAGE <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Display PID VPWR_B using the M-MDS. (See PID/DATA MONITOR INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is the voltage B+? 	Yes Go to the next step.
		No Inspect the ROOM 15 A, and HAZARD 25 A fuses. <ul style="list-style-type: none"> • If a fuse is burnt out: <ul style="list-style-type: none"> — Repair or replace the wiring harness which is shorted to ground. — Replace the burnt out fuse. • If a fuse is damaged: <ul style="list-style-type: none"> — Replace the damaged fuse. • All fuses are normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness which has an open circuit. Go to the next step.
7	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Switch the ignition ON (engine off or on) and wait for 10 s or more. • Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is DTC U3003:16 displayed? 	Yes Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
8	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.