
INTAKE SHUTTER VALVE INITIALIZATION [SKYACTIV-D 2.2]

id0140z7993200

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following item from the initial screen of the M-MDS.
 - (1) Select the "Powertrain".
3. Then, select the items from the screen menu in the following order.
 - (1) Select the "Initialization".
 - (2) Select the "ETB".
4. Perform the procedure according to the directions on the screen.