

DTC P0140:00	HO2S circuit no activity detected
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the input voltage from the HO2S when the following conditions are met. Under the following monitoring conditions, if the input voltage from the HO2S does not exceed 0.75 V even though the short term fuel trim is controlled up to 10 % for specified period, the PCM determines that the HO2S circuit is not activated. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Drive Mode 03 (Variable Valve Timing, A/F Sensor Heater, HO2S Heater, A/F Sensor, HO2S and TWC Repair Verification Drive Mode) Estimated temperature of the zirconia element inside the HO2S above 450 °C {842 °F} <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is an intermittent monitor (A/F sensor, HO2S). The check engine light illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM. PENDING CODE is available if the PCM detects the above malfunction condition during first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	<ul style="list-style-type: none"> Erratic signal from HO2S <ul style="list-style-type: none"> HO2S loose Exhaust system leakage HO2S connector or terminals malfunction HO2S heater malfunction Short to ground in wiring harness between HO2S terminal A and PCM terminal 2AI PCM connector or terminals malfunction Open circuit in wiring harness between HO2S terminal A and PCM terminal 2AI HO2S malfunction <ul style="list-style-type: none"> HO2S deterioration Engine malfunction <ul style="list-style-type: none"> Insufficient engine compression Engine coolant leakage to combustion chamber PCM malfunction

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA (MODE 2) <ul style="list-style-type: none"> Perform the Freeze Frame PID Data Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Is the DTC P0140:00 on FREEZE FRAME DATA (Mode 2)? 	Yes	Go to the next step.
		No	Go to the troubleshooting procedure for DTC on FREEZE FRAME DATA (Mode 2). (See DTC TABLE [SKYACTIV-G 2.0].)
2	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS HAVE BEEN RECORDED <ul style="list-style-type: none"> Have the FREEZE FRAME DATA (Mode 2)/ snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor, HO2S related) been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS on the repair order, then go to the next step.
3	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
4	VERIFY RELATED PENDING CODE AND/OR DTC <p>Note</p> <ul style="list-style-type: none"> If the fuel monitor, DTC P0132:00 is retrieved, ignore it until DTC P0140:00 is fixed. Switch the ignition to off, then to ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	Go to the next step.
5	INSPECT CURRENT SIGNAL STATUS OF HO2S <ul style="list-style-type: none"> Inspect the HO2S. (See HEATED OXYGEN SENSOR (HO2S) INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Go to the next step.
		No	Go to Step 13.
6	INSPECT INSTALLATION OF HO2S <ul style="list-style-type: none"> Inspect installation of HO2S. Is the HO2S installed securely? 	Yes	Go to the next step.
		No	Retighten the HO2S, then go to Step 15. (See HEATED OXYGEN SENSOR (HO2S) REMOVAL/ INSTALLATION [SKYACTIV-G 2.0].)
7	INSPECT EXHAUST SYSTEM FOR LEAKAGE <ul style="list-style-type: none"> Visually inspect for exhaust leakage between exhaust manifold and HO2S. Is there any leakage? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 15.
		No	Go to the next step.
8	INSPECT HO2S CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the HO2S connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
9	INSPECT HO2S HEATER <ul style="list-style-type: none"> Inspect the HO2S heater. (See HEATED OXYGEN SENSOR (HO2S) INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the HO2S, then go to Step 15. (See HEATED OXYGEN SENSOR (HO2S) REMOVAL/ INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
10	INSPECT HO2S SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the HO2S connector is disconnected. • Inspect for continuity between HO2S terminal A (wiring harness-side) and body ground. • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 15.
		No	Go to the next step.
11	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
12	INSPECT HO2S SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the HO2S and PCM connectors are disconnected. • Inspect for continuity between HO2S terminal A (wiring harness-side) and PCM terminal 2AI (wiring harness-side). • Is there continuity? 	Yes	Replace the HO2S, then go to Step 15. (See HEATED OXYGEN SENSOR (HO2S) REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 15.
13	INSPECT ENGINE COMPRESSION <ul style="list-style-type: none"> • Inspect the engine compression. (See COMPRESSION INSPECTION [SKYACTIV-G 2.0].) • Are compression pressures within specification? Specification: <ul style="list-style-type: none"> • Compression [European (L.H.D. U.K.) specs.] <ul style="list-style-type: none"> — Standard: 978 kPa {9.97 kgf/cm², 142 psi} (300 rpm) — Minimum: 783 kPa {7.98 kgf/cm², 114 psi} (300 rpm) — Maximum difference between cylinders: 166 kPa {1.69 kgf/cm², 24.1 psi} • Compression [Except European (L.H.D. U.K.) specs.] <ul style="list-style-type: none"> — Standard: 885 kPa {9.02 kgf/cm², 128 psi} (300 rpm) — Minimum: 708 kPa {7.22 kgf/cm², 103 psi} (300 rpm) — Maximum difference between cylinders: 150 kPa {1.53 kgf/cm², 21.8 psi} Note <ul style="list-style-type: none"> • Because the SKYACTIV-G 2.0 retards the intake valve closing timing, compression pressure is low. 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results, then go to Step 15.
14	INSPECT SEALING OF ENGINE COOLANT PASSAGE <ul style="list-style-type: none"> • Perform the "ENGINE COOLANT LEAKAGE INSPECTION". (See ENGINE COOLANT LEAKAGE INSPECTION [SKYACTIV-G 2.0].) • Does the radiator cap tester needle drop even though there is no engine coolant leakage from the radiator or the hoses? 	Yes	Engine coolant leakage from the engine (between the combustion chamber and the engine coolant passage) may have occurred. <ul style="list-style-type: none"> • Verify the conditions of the gasket and the cylinder head. <ul style="list-style-type: none"> — If there is any malfunction: <ul style="list-style-type: none"> • Repair or replace the malfunctioning part according to the inspection results, then go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
15	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the Drive Mode 03 (Variable Valve Timing, A/F Sensor Heater, HO2S Heater, A/F Sensor, HO2S and TWC Repair Verification Drive Mode). (See OBD DRIVE MODE [SKYACTIV-G 2.0].) • Is the PENDING CODE for this DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
16	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.