

id0119i2105200

- A coaxial reduction type starter has been adopted.

Diagram illustrating the location of the starter interlock switch (MTX) and the starter relay in the engine compartment. The starter interlock switch (MTX) is located near the battery. The starter relay is located in the fuse block. The starter motor is located at the bottom left of the diagram. An arrow indicates the vehicle front direction.

ac5wzn00001031

- Consists of the following parts:

Starter	(See STARTER [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
Starter relay	(See STARTER RELAY [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
Starter interlock switch (MTX)	(See STARTER INTERLOCK SWITCH [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)