

DTC P0133:00 [SKYACTIV-D 2.2]

id0102s4702400

DTC P0133:00	A/F sensor circuit no activity detected
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the A/F sensor impedance when the following conditions are met. If the impedance is more than threshold (40 Ω (cold), 100 Ω (hot)) for 5 s, the PCM determines that A/F sensor is not activated. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 11—16 V A/F sensor feedback correction is actuated <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (A/F sensor). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> PCM restricts engine torque. Inhibits the EGR control. Inhibits the diesel particulate filter regeneration control. Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> A/F sensor heater malfunction A/F sensor malfunction <ul style="list-style-type: none"> A/F sensor connector or terminals malfunction A/F sensor deterioration A/F sensor loose Exhaust system leakage PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA (MODE 2) <ul style="list-style-type: none"> Perform the Freeze Frame PID Data Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Is the DTC P0133:00 on FREEZE FRAME DATA (Mode 2)? 	Yes	Go to the next step.
		No	Go to the troubleshooting procedure for DTC on FREEZE FRAME DATA (Mode 2). (See DTC TABLE [SKYACTIV-D 2.2].)
2	VERIFY FREEZE FRAME DATA (MODE 2)/SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
3	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
4	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
5	INSPECT A/F SENSOR HEATER <ul style="list-style-type: none"> Inspect the A/F sensor heater. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the A/F sensor, then go to Step 10. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
6	INSPECT A/F SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the A/F sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
7	INSPECT CURRENT SIGNAL STATUS OF A/F SENSOR <ul style="list-style-type: none"> Reconnect all disconnected connectors. Inspect the A/F sensor. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Go to the next step.
		No	Go to Step 10.
8	INSPECT INSTALLATION OF A/F SENSOR <ul style="list-style-type: none"> Inspect installation of A/F sensor. Is the A/F sensor installed securely? 	Yes	Go to the next step.
		No	Retighten the A/F sensor, then go to Step 10. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
9	INSPECT EXHAUST SYSTEM FOR LEAKAGE <ul style="list-style-type: none"> Visually inspect for exhaust system. Is there any leakage? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step.
		No	Inspect the related wiring harness. <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the suspected wiring harness, then go to the next step. If there is no malfunction: <ul style="list-style-type: none"> Replace the A/F sensor, then go to the next step. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
10	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Perform the Drive Mode Type A. (See OBD DRIVE MODE [SKYACTIV-D 2.2].) Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.