


DTC U201F:12 [START STOP UNIT]



id0902p6024400

System malfunction location	Keyless receiver circuit malfunction
Detection condition	• Start stop unit detects keyless receiver circuit voltage of 6.2 V or more for 0.5 s or more .
Fail-safe	—
Possible cause	• Keyless receiver connector or terminal malfunction • Start stop unit connector or terminal malfunction • Short to power supply in wiring harness between start stop unit terminal 2Q and keyless receiver terminal A • Keyless receiver malfunction • Start stop unit malfunction


START STOP UNIT





START STOP UNIT
WIRING HARNESS-SIDE CONNECTOR



KEYLESS RECEIVER



KEYLESS RECEIVER
WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

Step	Inspection	Action	
1	INSPECT KEYLESS RECEIVER CONNECTOR CONDITION <ul style="list-style-type: none">• Switch the ignition to off.• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)• Disconnect the keyless receiver connector• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.• Is the connector normal?	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.

Step	Inspection	Action
2	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the start stop unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 5.
3	INSPECT KEYLESS RECEIVER CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Reconnect the start stop unit connector. • Verify that the keyless receiver connector is disconnected. • Connect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Switch the ignition ON (engine off or on). • Measure the voltage at the following terminals (vehicle wiring harness side). <ul style="list-style-type: none"> — Keyless receiver terminal A — Start stop unit terminal 2Q • Is the voltage 0 V? 	Yes Go to the next step.
		No Repair or replace the wiring harness which is shorted to power supply, then go to Step 5.
4	INSPECT KEYLESS RECEIVER <ul style="list-style-type: none"> • Inspect the keyless receiver. (See KEYLESS RECEIVER INSPECTION.) • Is the keyless receiver normal? 	Yes Go to the next step.
		No Replace the keyless receiver, then go to the next step. (See KEYLESS RECEIVER REMOVAL/INSTALLATION.)
5	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Reconnect all the disconnected connectors. • Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition ON (engine off or on) and wait for 0.5 s or more. • Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is DTC U201F:12 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
6	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.