







# DTC P081C:24 [START STOP UNIT]

id0902p6022800

<b>System malfunction location</b>	<b>NOT P position switch circuit malfunction</b>
<b>Detection condition</b>	<ul style="list-style-type: none"> <li>The start stop unit detects NOT P position switch is stuck off for <b>5 s or more</b> for a continuous <b>5 times</b> with the ignition switched ON (engine off or on).</li> </ul>
<b>Fail-safe</b>	<ul style="list-style-type: none"> <li>Perform the NOT P position switch control in a position other than P.</li> </ul>
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>Selector lever component connector or terminal malfunction</li> <li>Open circuit in wiring harness between selector lever component terminal I and body ground</li> <li>NOT P position switch malfunction</li> <li>Start stop unit connector or terminal malfunction</li> <li>Open circuit in wiring harness between start stop unit terminal 1J and selector lever component terminal B</li> <li>Start stop unit malfunction</li> </ul>
<div> <div> START STOP UNIT  </div> <div> NOT P POSITION SWITCH (SELECTOR LEVER COMPONENT)  </div> </div> <div> <div> START STOP UNIT WIRING HARNESS-SIDE CONNECTOR  </div> <div> SELECTOR LEVER COMPONENT WIRING HARNESS-SIDE CONNECTOR  </div> </div> <div>   </div>	

## Diagnostic Procedure

Step	Inspection	Action
1	<b>INSPECT SELECTOR LEVER COMPONENT CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Disconnect the selector lever component connector.</li> <li>Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>Is the connector normal?</li> </ul>	<div>Yes</div> Go to the next step. <div>No</div> Repair or replace the connector, then go to Step 6.

Step	Inspection	Action
2	<b>INSPECT NOT P POSITION SWITCH GROUND CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the selector lever component connector is disconnected.</li> <li>Inspect for continuity between selector lever component terminal I (vehicle wiring harness side) and body ground.</li> <li>Is there continuity?</li> </ul>	Yes Go to the next step.
		No Repair or replace the wiring harness which has an open circuit, then go to Step 6.
3	<b>INSPECT NOT P POSITION SWITCH</b> <ul style="list-style-type: none"> <li>Inspect the NOT P position switch. (See NOT P POSITION SWITCH INSPECTION.)</li> <li>Is the NOT P position switch normal?</li> </ul>	Yes Go to the next step.
		No Replace the selector lever component, then go to Step 6. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)
4	<b>INSPECT START STOP UNIT CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the start stop unit connector.</li> <li>Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>Is the connector normal?</li> </ul>	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 6.
5	<b>INSPECT NOT P POSITION SWITCH CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the start stop unit and selector lever component connectors are disconnected.</li> <li>Inspect the wiring harness for continuity between start stop unit terminal 1J (vehicle wiring harness side) and selector lever component terminal B (vehicle wiring harness side).</li> <li>Is there continuity?</li> </ul>	Yes Go to the next step.
		No Repair or replace the wiring harness which has an open circuit, then go to the next step.
6	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>Reconnect all the disconnected connectors.</li> <li>Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].)</li> <li>Switch the ignition ON (engine off).</li> <li>Perform the following work <b>5 or more times</b>. <ul style="list-style-type: none"> <li>Operate the selector lever to positions from other than P and hold for <b>5 s or more</b>.</li> <li>Operate the selector lever to position P and hold for <b>5 s or more</b>.</li> <li>Operate the selector lever to positions from other than P.</li> </ul> </li> <li>Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].)</li> <li>Is DTC P081C:24 displayed?</li> </ul>	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.

---

Step	Inspection		Action
7	<b>VERIFY IF OTHER DTCs DISPLAYED</b> • Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No	DTC troubleshooting completed.