

**DTC U2100:00**

id030200201500

<b>DTC U2100:00</b>	<b>Configuration data not recorded</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"><li>• 4WD CM detects configuration data not record</li></ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"><li>• 4WD operates by the specified data.</li><li>• 4WD warning light: Illuminated</li></ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Module configuration procedure is not done properly</li></ul>

**Diagnostic procedure**

<b>STEP</b>	<b>INSPECTION</b>	<b>ACTION</b>
1	<b>COUPLING COMPONENT CALIBRATION DATA WRITING</b> <ul style="list-style-type: none"><li>• Write the coupling component calibration data. (See COUPLING COMPONENT CALIBRATION DATA WRITING.)</li><li>• Clear the DTCs from the memory. (See ELECTRONIC 4WD CONTROL SYSTEM ON-BOARD DIAGNOSIS.)</li><li>• Is the same DTC present?</li></ul>	Go to the next step.
2	<b>VERIFY THAT THE SAME DTC IS NOT PRESENT</b> <ul style="list-style-type: none"><li>• Clear the DTCs from the memory. (See ELECTRONIC 4WD CONTROL SYSTEM ON-BOARD DIAGNOSIS.)</li><li>• Is the same DTC present?</li></ul>	Yes Repeat the inspection from Step 1.
		No Go to the next step.
3	<b>VERIFY THAT NO OTHER DTCS ARE PRESENT</b> <ul style="list-style-type: none"><li>• Are any other DTCs output?</li></ul>	Yes Go to the applicable DTC inspection. (See ELECTRONIC 4WD CONTROL SYSTEM ON-BOARD DIAGNOSIS.)
		No DTC troubleshooting completed.