

---

## OIL PRESSURE SWITCH REMOVAL/INSTALLATION

id092200029100

### Note

- For the oil pressure switch removal/installation, refer to the engine oil solenoid valve removal installation because the oil pressure switch is installed to the engine oil solenoid valve. (See ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)