


**DTC P0A8D:00 [SKYACTIV-G 2.0]**

id0102h1009400

<b>DTC P0A8D:00</b>	<b>Power supply system circuit low input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"><li>Any of the values for the battery voltage, voltage for PCM control, and voltage for DC-DC converter control is low when the engine is started.</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>This is a continuous monitor (other).</li><li>The check engine light does not illuminate.</li><li>FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.</li><li>The DTC is stored in the PCM memory.</li></ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"><li>Inhibits engine-stop by operating the i-stop function.</li><li>Inhibits a part of the generator output control.</li></ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>Battery malfunction</li><li>DC-DC converter connector or terminals malfunction</li><li>Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none"><li>Short to ground in wiring harness between DCDC 50 A fuse and DC-DC converter terminal L</li><li>DCDC 50 A fuse malfunction</li><li>Open circuit in wiring harness between battery positive terminal and DC-DC converter terminal L</li></ul></li><li>Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none"><li>Short to ground in wiring harness between C/U IG1 15 A fuse and DC-DC converter terminal H</li><li>C/U IG1 15 A fuse malfunction</li><li>Open circuit in wiring harness between IG1 relay terminal C and DC-DC converter terminal H</li></ul></li><li>PCM connector or terminals malfunction</li><li>DC-DC converter malfunction</li><li>Current sensor malfunction</li><li>Front body control module (FBCM) malfunction</li><li>PCM malfunction</li></ul>

**DTC P0A8D:**  
**00**

**Power supply system circuit low input**



**Diagnostic Procedure**

STEP	INSPECTION		ACTION
1	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> • Switch the ignition to off, then to ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	Go to the next step.
3	<b>CONFIRM FRONT BODY CONTROL MODULE (FBCM) DTC</b> • Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
4	<b>INSPECT BATTERY</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-G 2.0].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Recharge or replace the battery, then go to Step 10. (See BATTERY RECHARGING [SKYACTIV-G 2.0].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
5	<b>INSPECT DC-DC CONVERTER CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the DC-DC converter connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	<b>INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the DC-DC converter connector is disconnected.</li> <li>Measure the voltage at the DC-DC converter terminal L (wiring harness-side).</li> <li>Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the DCDC 50 A fuse. <ul style="list-style-type: none"> <li>If the fuse is blown:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness for a possible short to ground.</li> <li>Replace the fuse.</li> </ul> </li> <li>If the fuse is deteriorated:               <ul style="list-style-type: none"> <li>Replace the fuse.</li> </ul> </li> <li>If the fuse is normal:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness for a possible open circuit.</li> </ul> </li> </ul> Go to Step 10.
7	<b>INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>Verify that the DC-DC converter connector is disconnected.</li> <li>Switch the ignition ON (engine off or on).</li> <li>Measure the voltage at the DC-DC converter terminal H (wiring harness-side).</li> <li>Is the voltage <b>B+</b>?</li> </ul>	Yes	Go to the next step.
		No	Inspect the C/U IG1 15 A fuse. <ul style="list-style-type: none"> <li>If the fuse is blown:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness for a possible short to ground.</li> <li>Replace the fuse.</li> </ul> </li> <li>If the fuse is deteriorated:               <ul style="list-style-type: none"> <li>Replace the fuse.</li> </ul> </li> <li>If the fuse is normal:               <ul style="list-style-type: none"> <li>Repair or replace the wiring harness for a possible open circuit.</li> </ul> </li> </ul> Go to Step 10.
8	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition to off.</li> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
9	<b>INSPECT DC-DC CONVERTER</b> <ul style="list-style-type: none"> <li>Inspect the DC-DC converter. (See DC-DC CONVERTER INSPECTION [SKYACTIV-G 2.0].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the DC-DC converter, then go to the next step. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Replace the current sensor, then go to the next step. (See CURRENT SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
10	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Make sure to reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].)</li> <li>Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)</li> </ul> Go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
11	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.