

DTC U2100:00 [START STOP UNIT]

id0902p6024500

System malfunction location	Start stop unit configuration not completed
Detection condition	<ul style="list-style-type: none"> Start stop unit configuration not completed.
Fail-safe	<ul style="list-style-type: none"> Although the engine cannot be started with the ignition switched OFF (LOCK) or to ACC, if the ignition is switched ON (engine off), the engine can be started. <p>Note</p> <ul style="list-style-type: none"> If the start stop unit configuration is not completed, the start stop unit setting will be for an ATX vehicle. For MTX vehicles, if the start stop unit cannot receive the CAN signal, the engine cannot be started because the vehicle cannot be recognized as a MTX vehicle.
Possible cause	<ul style="list-style-type: none"> Start stop unit configuration error Start stop unit malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM START STOP UNIT CONFIGURATION <ul style="list-style-type: none"> Perform the start stop unit configuration using the M-MDS. (See START STOP UNIT CONFIGURATION (USING AS-BUILT DATA).) Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) Is DTC U2100:00 displayed? 	Yes Perform the start stop unit configuration again, then go to the next step. (See START STOP UNIT CONFIGURATION (USING AS-BUILT DATA).)
		No Go to Step 3.
2	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) Is DTC U2100:00 displayed? 	Yes Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
3	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.