

**ALL POWER WINDOWS OTHER THAN DRIVER-SIDE DO NOT OPERATE USING THE POWER WINDOW SUBSWITCH [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR DRIVER-SIDE)]
[POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)]**

id090360931200

3	All power windows other than driver-side do not operate using the power window subswitch
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Open or short circuit in power window subswitch wiring harness (battery power supply circuit). • Power window subswitch malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	<ul style="list-style-type: none"> • Switch the ignition ON (engine off or on). • Set the power cut-switch to the UNLOCK position. • Measure the voltage at the power window subswitch terminal C. • Is the voltage B+? 	Yes Replace the power window subswitch. (See POWER WINDOW SUBSWITCH REMOVAL/ INSTALLATION.)
		No Inspect for an open or short circuit in the wiring harness at power window subswitch (battery power supply). Inspect the power window subswitch connector connection. (damage/pulled-out pins, corrosion) Repair or replace if necessary.