


OIL SEAL (DIFFERENTIAL) REPLACEMENT [D66M-R, D66MX-R]


id0515md160100

1. Remove the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
2. Drain the manual transaxle oil. (See MANUAL TRANSAXLE OIL REPLACEMENT [D66M-R, D66MX-R].)
3. Disconnect the drive shaft (LH) from the manual transaxle. (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
4. Disconnect the drive shaft (RH) from the manual transaxle. (2WD) (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
5. Remove the drive shaft (RH). (4WD) (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
6. Remove the front crossmember component and No.1 engine mount rubber as a single unit. (4WD) (See FRONT CROSSMEMBER REMOVAL/INSTALLATION.)
7. Remove the transfer. (4WD) (See TRANSFER REMOVAL/INSTALLATION [D66MX-R].)
8. Remove the oil seal (LH).




ac5wzw00003500

9. Remove the oil seal (RH).
2WD




ac5wzw00003501

4WD



ac5wzw00003502


10. Using the **SSTs** and a hammer, tap a new oil seal (LH) in evenly until the **SST** (49 U027 003) contacts the transaxle case.



ac5wzw00003503

11. Using the **SSTs** and a hammer, tap a new oil seal (RH) in evenly until the **SST** (49 U027 003) contacts the transaxle case.


2WD



ac5wzw00003504

4WD

12. Coat the lip of each oil seal with manual transaxle oil.
13. Install the transfer. (4WD) (See TRANSFER REMOVAL/INSTALLATION [D66MX-R].)
14. Install the front crossmember component and No.1 engine mount rubber as a single unit. (4WD) (See FRONT CROSSMEMBER REMOVAL/INSTALLATION.)
15. Install the drive shaft (RH). (4WD) (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
16. Install the drive shaft (RH) from the manual transaxle. (2WD) (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
17. Install the drive shaft (LH) from the manual transaxle. (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
18. Add the specified amount of specified manual transaxle oil. (See MANUAL TRANSAXLE OIL REPLACEMENT [D66M-R, D66MX-R].)
19. Install the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)



ac5wzw00003505