
DTC B1206:00/U2107:00

id080200890100

System malfunction location	<ul style="list-style-type: none">• B1206:00: SAS control module operation (deployment) (fuel cut signal output)• U2107:00: SAS control module operation (deployment) signal output
Detection condition	Warning <ul style="list-style-type: none">• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure. <ul style="list-style-type: none">• SAS control module operates (deploys) (air bag module or pre-tensioner seat belt)
Fail-safe	—
Possible cause	<ul style="list-style-type: none">• SAS control module operation (deployment)• SAS control module malfunction
System wiring diagram	—

Diagnostic Procedure

ACTION
<ul style="list-style-type: none">• Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION.)