
FUEL PUMP CONTROL MODULE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0114z9175100

1. Perform the KOEO self-test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
2. Verify that a fuel pump control module related DTC is detected. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
 - If DTCs are detected, repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
 - If a DTC is not detected, go to the next step.
3. Inspect the following:
 - Fuel pump control module damage
 - Fuel pump control module connector damage or corrosion
 - If there is any malfunction, repair or replace the malfunctioning part.