
FUEL FILTER WATER DRAINING [SKYACTIV-D 2.2]

id0114z7777600

1. Remove the fuel filter. (See FUEL FILTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
2. Loosen the drain plug for the lower part of the fuel filter.
3. Drain the water.
4. After draining the water, tighten the drain plug by hand sufficiently.