

## DTC U3000:09 [BLIND SPOT MONITORING (BSM)]

id0902i3393100

<b>System malfunction location</b>	BSM control module internal malfunction
<b>Detection condition</b>	• The BSM control module detected a malfunction inside the voltage control oscillator.
<b>Fail-safe</b>	• BSM is stopped.
<b>Possible cause</b>	• BSM control module malfunction
<b>System wiring diagram</b>	—

### Diagnostic Procedure

Diagnostic Procedure			
Step	Inspection	Action	
1	<b>PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS BSM CONTROL MODULE</b> <ul style="list-style-type: none"><li>• Clear BSM control module DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].)</li><li>• Perform the DTC inspection for the BSM control module using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].)</li><li>• Is the DTC U3000:09 displayed?</li></ul>	Yes	Replace the BSM control module, then go to the next step. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
2	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"><li>• Are any other DTCs displayed?</li></ul>	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BLIND SPOT MONITORING (BSM)].)
		No	DTC troubleshooting completed.