

DTC P0555:00 [SKYACTIV-D 2.2]

id0102s4950200

DTC P0555:00	Power brake unit vacuum sensor circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the power brake unit vacuum sensor signal voltage while the ignition switch is ON. If the PCM detects the power brake unit vacuum sensor voltage is below 0.15 V or above 4.8 V, the PCM determines that the power brake unit vacuum sensor circuit has problem. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Power brake unit vacuum sensor connector or terminals malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> Power brake unit vacuum sensor terminal C—PCM terminal 2BB Power brake unit vacuum sensor terminal B—PCM terminal 2BC PCM connector or terminals malfunction Short to power supply in wiring harness between power brake unit vacuum sensor terminal B and PCM terminal 2BC Power brake unit vacuum sensor circuits are shorted to each other Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Power brake unit vacuum sensor terminal C—PCM terminal 2BB Power brake unit vacuum sensor terminal B—PCM terminal 2BC Power brake unit vacuum sensor terminal A—PCM terminal 2BD Power brake unit vacuum sensor malfunction PCM malfunction
<div> <div> <div>⑨</div> <div>POWER BRAKE UNIT VACUUM SENSOR</div> </div> <div> <div>PCM</div> </div> <div> <div>POWER BRAKE UNIT VACUUM SENSOR WIRING HARNESS-SIDE CONNECTOR</div> </div> <div> <div>PCM WIRING HARNESS-SIDE CONNECTOR</div> </div> </div>	

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes No	Go to the next step. Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	INSPECT POWER BRAKE UNIT VACUUM SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the power brake unit vacuum sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	INSPECT POWER BRAKE UNIT VACUUM SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the power brake unit vacuum sensor connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Power brake unit vacuum sensor terminal C — Power brake unit vacuum sensor terminal B • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 10.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	INSPECT POWER BRAKE UNIT VACUUM SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the power brake unit vacuum sensor and PCM connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the power brake unit vacuum sensor terminal B (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 10.
7	INSPECT POWER BRAKE UNIT VACUUM SENSOR CIRCUITS FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the power brake unit vacuum sensor and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between power brake unit vacuum sensor terminals C, B and A (wiring harness-side). • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 10.
		No	Go to the next step.
8	INSPECT POWER BRAKE UNIT VACUUM SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the power brake unit vacuum sensor and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Power brake unit vacuum sensor terminal C —PCM terminal 2BB — Power brake unit vacuum sensor terminal B —PCM terminal 2BC — Power brake unit vacuum sensor terminal A —PCM terminal 2BD • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 10.

STEP	INSPECTION	ACTION	
9	INSPECT POWER BRAKE UNIT VACUUM SENSOR <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Inspect the power brake unit vacuum sensor. (See POWER BRAKE UNIT VACUUM SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the power brake unit vacuum sensor, then go to the next step. (See POWER BRAKE UNIT VACUUM SENSOR REMOVAL/INSTALLATION.)
		No	Go to the next step.
10	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.