

DTC U3000:49 [FRONT BODY CONTROL MODULE (FBCM)]

id0902p2011400

System malfunction location	Front body control module (FBCM) internal malfunction
Detection condition	• Malfunction inside front body control module (FBCM) detected.
Fail-safe	—
Possible cause	• Front body control module (FBCM) malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS FRONT BODY CONTROL MODULE (FBCM) <ul style="list-style-type: none">• Clear front body control module (FBCM) DTCs using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].)• Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)• Is DTC U3000:49 displayed?	Yes replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
2	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.